USF... LKF... UYN... USN... LKN... UEG... LEG... UYG... USG... LKG... UET... LET... UST... LKT... LEC... LYC... USC... LKC... UED... LED... UYD... LYD... USD...

LKD...



SG762.B FAG

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FAG	INTERCHANGE
		FKL
INTERCHANGE		FKL
FKL	USS	FKL
NTN	<u>-</u>	FKL
SKF	<u>-</u>	FKL
INA	<u>-</u>	FKL
NSK		FKL
коуо		FKL
FKL	UYS	FKL
FKL	<u>LKS</u>	FKL
FKL	<u>UEV</u>	FKL
FKL	LEV	FKL
FKL	<u>UYV</u>	FKL
FKL	<u>LYV</u>	FKL
FKL	<u>USV</u>	FKL
FKL	<u>LKV</u>	FKL
FKL	<u>UEU</u>	FKL
FKL	<u>LEU</u>	FKL
FKL	<u>UYU</u>	FKL
FKL	LYU	FKL
FKL	<u>USU</u>	FKL
FKL	<u>LKU</u>	FKL
FKL	<u>UYF</u>	FKL
		FKL
		• • • •





Bearings

INTERCHANGE		INTERCHANGE	
FKL	LEP	SKF	FYJ.FM
FKL	UYP	FAG	FG162
FKL	<u>LYP</u>	INA	<u>PCJ</u>
FKL	USP	NTN	<u>AELF</u>
FKL	LKP	KOYO	SAF
FKL	LER	FAG	FG762.B
FKL	LYR	SKF	<u>FYJ.KF</u>
FKL	USR	NSK	<u>UKF</u>
FKL	LKR	NTN	<u>UKF</u>
SKF	SYJ.FM	KOYO	UKF
FAG	SG162	SKF	FYTJ.FM_
INA	PASE	INA	PCJT
NSK	ENP	NTN	<u>AELFL</u>
KOYO	SAP	KOYO	SAFL
FAG	<u>-</u>	SKF	FYTJ.KF
SKF	SYJ.KF	NSK	UKFL
NSK	UKP	NTN	UKFL
NTN	UKP	KOYO	UKFL
KOYO	UKP	SKF	FYC.RM
SKF	SYFJ.RM	NSK	UBFC
NSK	UBPA	NTN	ASFC
NTN	ASUP	KOYO	SBFC
KOYO	SBPA	SKF	FYC.TF
SKF	SYFJ.TF	NSK	UCFC
NSK	UCPA	NTN	UCFC
NTN	UCUP	KOYO	UCFC
KOYO	UCPA	SKF	FYC.FM
SKF	SYFJ.FM	NTN	AELFC
NTN	AELUP	SKF	FYC.KF
KOYO	SAPA	NSK	UKFC
SKF	SYFJ.WF	NTN	UKFC
NSK	EWPA	KOYO	UKFC
NTN	UELUP	SKF	TU.RM
KOYO	NAPA	NSK	UBT
SKF	SYFJ.KF	NTN	AST
NSK	UKPA	KOYO	SBT
NTN	UKUP	SKF	<u>TU.TF</u>
KOYO	UKPA	NSK	UCT
SKF	SYF.RM	NTN	UCT
INA	PSHEY	KOYO	UCT
SKF	SYF TF	SKF	TU.KF
INA	RSHEY	NSK	UKT
SKF	SYF.FM	NTN	UKT
INA	PSHE	KOYO	UKT
SKF	SYF.WF	SKF	PF TF
INA	RSHE	FAG	FB562
SKF	SYF.KF	INA	RRY
KOYO		SKF	PF.WF
			<u></u>





Bearings

INTERCHANGE		INTERCHANGE	
FAG	FB362.B	SKF	<u>FYTJ.WF</u>
INA	RR	INA	RCJT
FAG	FB762.B	NSK	<u>EWFL</u>
SKF	PFD.RM	NTN	<u>UELFL</u>
INA	<u>PATRY</u>	KOYO	<u>NAFL</u>
SKF	PFD.TF	SKF	FYC.WF
INA	RRTRY	INA	<u>RFE</u>
SKF	PFD.FM_	NSK	<u>EWFC</u>
INA	<u>RATR</u>	NTN	<u>UELFC</u>
SKF	PFD.WF	KOYO	NAFC
INA	<u>RRTR</u>	SKF	TU.FM
SKF	PFT TF	INA	PTUE
INA	RRTY	NSK	<u>ENT</u>
NSK	<u>ENPFL</u>	NTN	<u>AELT</u>
SKF	PFT.FM_	KOYO	SAT
INA	RAT	SKF	TU.WF
NTN	<u>AELPFL</u>	INA	RTUE
KOYO	SAPFL	NSK	<u>EWT</u>
SKF	PFT.WF	NTN	<u>UELT</u>
INA	RRT	KOYO	<u>NAT</u>
SKF	P TF	SKF	PF.RM
SKF	P.WF	INA	RAY
FAG	SB762.B	NSK	<u>UBPF</u>
FKL	<u>UES</u>	NTN	<u>ASPF</u>
FKL	<u>UEN</u>	KOYO	<u>SBPF</u>
FKL	LEN	SKF	PFT.RM
FKL	LYN	INA	RATY
FKL	LYG	NSK	<u>UBPFL</u>
FKL	UYT	NTN	ASPFL
FKL	LYT	KOYO	SBPFL
FKL	UEC	SKF	P.RM
FKL	<u>UEP</u>	INA	PBY
FKL	<u>UER</u>	NSK	<u>UBPP</u>
SKF	SYJ.RM	NTN	ASPP
INA	<u>PASEY</u>	KOYO	<u>SBPP</u>
NSK	<u>UBP</u>		
NTN	<u>ASP</u>		
КОУО	<u>SBP</u>		
SKF	FYTJ.RM_		
INA	<u>PCJTY</u>		
NSK	<u>UBFL</u>		
NTN	<u>ASFL</u>		
KOYO	SBFL		
SKF	FYTJ.TF		
INA	RCJTY		
NSK	UCLF		
NTN	UCFL		
коуо	UCFL		

