

LEV... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FKL	INTERCHANGE	
		FKL	<u>USG</u>
		FKL	<u>LKG</u>
INA	-	FKL	<u>UET</u>
	SYFJ.TF	FKL	LET
NSK	<u>UCPA</u>	FKL	UST
NTN	UCUP	FKL	LKT
КОҮО	<u>UCPA</u>	FKL	USC
FKL	<u>USS</u>	FKL	LKC
FKL	<u>LKS</u>	FKL	USD
FKL	<u>UEV</u>	FKL	LKD
FKL	<u>UYV</u>	FKL	USP
FKL	<u>LYV</u>	FKL	LKP
FKL	<u>USV</u>	FKL	LER
FKL	<u>LKV</u>	FKL	LYR
FKL	<u>USU</u>	FKL	USR
FKL	<u>LKU</u>	FKL	LKR
FKL	<u>USF</u>	NTN	-
FKL	<u>LKF</u>	SKF	
FKL	<u>USN</u>	FAG	SG762.B
FKL	<u>LKN</u>	NSK	
FKL	<u>UEG</u>	KOYO	-
FKL	LEG	FAG	
FKL	<u>UYG</u>	SKF	SYJ.KF
		NSK	UKP





Bearings

INTERCHANGE		INTERCHANGE	
NTN	UKP	NTN	UCT
КОҮО	UKP	КОҮО	UCT
SKF	SYFJ.RM	SKF	TU.KF
NSK	UBPA	NSK	UKT
NTN	ASUP	NTN	UKT
КОҮО	SBPA	КОҮО	UKT
SKF	SYFJ.FM	FAG	FB762.B
NTN	AELUP	SKF	P TF
КОҮО	SAPA	SKF	P.WF
SKF	SYFJ.WF	FAG	SB762.B
NSK	EWPA	FKL	UES
NTN	UELUP	FKL	UYS
КОҮО	NAPA	FKL	UEU
SKF	SYFJ.KF	FKL	LEU
NSK	UKPA	FKL	UYU
NTN	UKUP	FKL	LYU
КОҮО	UKPA	FKL	UYF
SKF	SYF.KF	FKL	UEN
КОҮО		FKL	LEN
FAG	 FG762.B	FKL	 UYN
SKF	FYJ.KF	FKL	LYN
NSK	UKF	FKL	LYG
NTN	UKF	FKL	UYT
КОҮО	UKF	FKL	 LYT
SKF	FYTJ.KF	FKL	UEC
NSK	UKFL	FKL	 LEC
NTN	UKFL	FKL	LYC
КОҮО	UKFL	FKL	UED
SKF	FYC.RM	FKL	LED
NSK	UBFC	FKL	 UYD
NTN	ASFC	FKL	<u>LYD</u>
КОҮО	SBFC	FKL	UEP
SKF	FYC.TF	FKL	LEP
NSK	UCFC	FKL	 UYP
NTN	UCFC	FKL	LYP
КОҮО	UCFC	FKL	<u>UER</u>
SKF	FYC.FM	SKF	SYJ.RM
NTN	AELFC	INA	PASEY
SKF	FYC.KF	NSK	UBP
NSK	UKFC	NTN	ASP
NTN	UKFC	КОҮО	SBP
КОҮО	UKFC	SKF	SYJ.FM
SKF	TU.RM	FAG	SG162
NSK	UBT	INA	PASE
NTN	AST	NSK	ENP
КОҮО	SBT	KOYO	SAP
SKF		SKF	
	TU.TF		SYF.RM
NSK	UCT	INA	PSHEY





Bearings

INTERCHANGE	INTERCHANGE	
SKF <u>S</u>	SYF TF NTN	ASPF
INA R	RSHEY KOYO	SBPF
SKF <u>SY</u>	SYF.FM SKF	<u>PF TF</u>
INA	PSHE FAG	FB562
SKF <u>SY</u>	YF.WF INA	<u>RRY</u>
INA	<u>RSHE</u> SKF	PF.WF
SKF F	FYJ.FM FAG F	B362.B
FAG	FG162 INA	RR
INA	PCJ SKF	PFD.RM
NTN	AELF INA	PATRY
КОҮО	SAF SKF	PFD.TF
SKF FY	<u>YTJ.RM</u> INA	RRTRY
INA	PCJTY SKF	PFD.FM
NSK	UBFL INA	RATR
NTN	ASFL SKF	PFD.WF
КОҮО	<u>SBFL</u> INA	RRTR
SKF <u>FY</u>	YTJ.TF SKF	PFT.RM
INA	RCJTY INA	RATY
NSK	UCLF NSK	<u>UBPFL</u>
NTN	UCFL NTN	ASPFL
КОҮО	UCFL KOYO	SBPFL
SKF FY	YTJ.FM SKF	PFT TF
INA	PCJT INA	<u>RRTY</u>
NTN	AELFL NSK	ENPFL
КОҮО	SAFL SKF	PFT.FM
SKF <u>FY</u>	<u>YTJ.WF</u> INA	RAT
INA	RCJT NTN	AELPFL
NSK	EWFL KOYO	SAPFL
NTN	UELFL SKF	PFT.WF
КОҮО	NAFL INA	RRT
SKF FY	YC.WF SKF	P.RM
INA	RFE INA	PBY
NSK	EWFC NSK	<u>UBPP</u>
NTN U	UELFC NTN	ASPP
КОҮО	NAFC KOYO	<u>SBPP</u>
SKF <u>T</u>	TU.FM	
INA	PTUE	
NSK	ENT	
NTN	AELT	
КОҮО	SAT	
SKF <u>T</u>	TU.WF	
INA	RTUE	
NSK	EWT	
NTN	UELT	
коүо	NAT	
SKF P	<u>PF.RM</u>	
INA	RAY	
NSK	<u>UBPF</u>	

