USC...



AELUP NTN

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	NTN	INTERCHANGE	
		FKL	USF
INTERCHANGE		FKL	LKF
FKL	<u>UYV</u>	FKL	UEN
FAG	<u>-</u>	FKL	LEN
INA	<u>.</u>	FKL	UYN
NSK	_	FKL	LYN
SKF	SYFJ.FM_	FKL	USN
KOYO	<u>SAPA</u>	FKL	LKN
FKL	<u>UES</u>	FKL	UEG
FKL	<u>USS</u>	FKL	LEG
FKL	<u>LKS</u>	FKL	UYG
FKL	<u>UEV</u>	FKL	<u>LYG</u>
FKL	LEV	FKL	USG
FKL	<u>LYV</u>	FKL	<u>LKG</u>
FKL	USV	FKL	UET
FKL	LKV	FKL	LET
FKL	UEU	FKL	UYT
FKL	LEU	FKL	
FKL	UYU		LYT
FKL	LYU	FKL	UST
FKL	USU	FKL	LKT
FKL	LKU	FKL	UEC
FKL	UYF	FKL	LEC
	271111	FKL	LYC

FKL





Bearings

INTERCHANGE		INTERCHANGE	
FKL	LKC	INA	<u>PSHEY</u>
FKL	UED	SKF	SYF TF
FKL	LED	INA	RSHEY
FKL	UYD	SKF	SYF.FM
FKL	LYD	INA	<u>PSHE</u>
FKL	USD	SKF	SYF.WF
FKL	LKD	INA	RSHE
FKL	UEP	SKF	SYF.KF
FKL	LEP	KOYO	<u></u>
FKL	UYP	SKF	FYJ.FM
FKL	LYP	FAG	FG162
FKL	USP	INA	PCJ
FKL	LKP	NTN	<u>AELF</u>
FKL	UER	KOYO	SAF
FKL	LER	FAG	FG762.B
FKL	LYR	SKF	FYJ.KF
FKL	USR	NSK	UKF
FKL	LKR	NTN	UKF
SKF	SYJ.RM	KOYO	UKF
INA	PASEY	SKF	FYTJ.RM
NSK	UBP	INA	PCJTY
NTN	ASP	NSK	UBFL
KOYO	SBP	NTN	ASFL
NTN		KOYO	SBFL
SKF	-	SKF	FYTJ.TF
FAG	SG762.B	INA	RCJTY
KOYO	-	NSK	UCLF
SKF	SYJ.KF	NTN	UCFL
NSK	UKP	KOYO	UCFL
NTN	UKP	SKF	FYTJ.FM
KOYO	UKP	INA	PCJT
SKF	SYFJ.RM	NTN	AELFL
NSK	UBPA	KOYO	SAFL
NTN	ASUP	SKF	FYTJ.WF
KOYO	SBPA	INA	RCJT
SKF	SYFJ.TF	NSK	EWFL
NSK	UCPA	NTN	UELFL
NTN	UCUP	KOYO	NAFL
KOYO	UCPA	SKF	FYTJ.KF
SKF	SYFJ.WF	NSK	UKFL
NSK	EWPA	NTN	UKFL
NTN	UELUP	KOYO	UKFL
KOYO	NAPA	SKF	FYC.RM
SKF	SYFJ.KF	NSK	UBFC
NSK	UKPA	NTN	ASFC
NTN	UKUP	коуо	SBFC
KOYO	UKPA	SKF	FYC.TF
SKF	SYF.RM	NSK	UCFC





Bearings

INTERCHANGE		INTERCHANGE	
NTN	<u>UCFC</u>	INA	PATRY
KOYO	<u>UCFC</u>	SKF	PFD.TF
SKF	FYC.FM	INA	RRTRY
NTN	<u>AELFC</u>	SKF	PFD.FM
SKF	FYC.WF	INA	RATR
INA	RFE	SKF	PFD.WF
NSK	<u>EWFC</u>	INA	RRTR
NTN	<u>UELFC</u>	SKF	PFT.RM
KOYO	<u>NAFC</u>	INA	RATY
SKF	FYC.KF	NSK	<u>UBPFL</u>
NSK	<u>UKFC</u>	NTN	<u>ASPFL</u>
NTN	<u>UKFC</u>	KOYO	<u>SBPFL</u>
KOYO	<u>UKFC</u>	SKF	PFT TF
SKF	TU.RM	INA	RRTY
NSK	<u>UBT</u>	NSK	<u>ENPFL</u>
NTN	<u>AST</u>	SKF	PFT.FM
KOYO	SBT	INA	RAT
SKF	<u>TU.TF</u>	NTN	<u>AELPFL</u>
NSK	<u>UCT</u>	KOYO	SAPFL
NTN	<u>UCT</u>	SKF	PFT.WF
KOYO	<u>UCT</u>	INA	RRT
SKF	TU.FM_	SKF	P.RM
INA	PTUE	INA	PBY
NSK	<u>ENT</u>	NSK	<u>UBPP</u>
NTN	<u>AELT</u>	NTN	ASPP
KOYO	SAT	KOYO	SBPP
SKF	TU.WF	SKF	<u>P TF</u>
INA	RTUE	SKF	P.WF
NSK	<u>EWT</u>	FAG	<u>SB762.B</u>
NTN	<u>UELT</u>	FKL	UYS
KOYO	NAT	SKF	SYJ.FM
SKF	TU.KF	FAG	SG162
NSK	<u>UKT</u>	INA	PASE
NTN	<u>UKT</u>	NSK	ENP
KOYO	<u>UKT</u>	KOYO	SAP
SKF	PF.RM		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	ASPF		
KOYO	SBPF_		
SKF	PF TF		
FAG	FB562		
INA	RRY		
SKF	PF.WF		
	FB362.B		
INA	RR EB762 B		
FAG SKF	FB762.B		
JNF	PFD.RM		

