LKF... UEN... LEN... UYN... LYN... USN... LKN... UEG... LEG... UYG... LYG... USG... LKG... UET... LET... UYT... LYT... UST... LKT... UEC... USC... LKC... UED...

LED...



UKPA KOYO

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	KOYO	INTERCHANGE
INTERCUANCE		FKL
INTERCHANGE	1107	FKL
FKL	<u>LKV</u>	FKL
FAG	<u>-</u>	FKL
INA	<u>-</u>	FKL
SKF	SYFJ.KF	FKL
NSK	<u>UKPA</u>	FKL
NTN	<u>UKUP</u>	FKL
FKL	<u>UES</u>	FKL
FKL	<u>USS</u>	FKL
FKL	<u>LKS</u>	FKL
FKL	<u>UEV</u>	FKL
FKL	LEV	FKL
FKL	<u>UYV</u>	FKL
FKL	<u>LYV</u>	FKL
FKL	<u>USV</u>	FKL
FKL	UEU	FKL
FKL	LEU	FKL
FKL	<u>UYU</u>	FKL
FKL	LYU	FKL
FKL	<u>USU</u>	FKL
FKL	LKU	FKL
FKL	USF	FKL
		ΓNL

FKL





Bearings

INTERCHANGE		INTERCHANGE	
FKL	UYD	SKF	SYF.FM
FKL	LYD	INA	PSHE
FKL	USD	SKF	SYF.WF
FKL	LKD	INA	RSHE
FKL	UEP	SKF	SYF.KF
FKL	LEP	KOYO	<u></u>
FKL	UYP	FAG	FG762.B
FKL	LYP	SKF	FYJ.KF
FKL	USP	NSK	<u>UKF</u>
FKL	LKP	NTN	UKF
FKL	UER	KOYO	<u>UKF</u>
FKL	LER	SKF	FYTJ.RM
FKL	LYR	INA	<u>PCJTY</u>
FKL	USR	NSK	UBFL
FKL	LKR	NTN	ASFL
SKF	SYJ.RM	KOYO	SBFL
INA	PASEY	SKF	FYTJ.TF
NSK	UBP	INA	RCJTY
NTN	ASP	NSK	UCLF
KOYO	SBP	NTN	UCFL
NTN	-	KOYO	UCFL
SKF	-	SKF	FYTJ.FM
FAG	SG762.B	INA	PCJT
NSK	-	NTN	AELFL
KOYO	-	KOYO	SAFL
SKF	SYJ.KF	SKF	FYTJ.WF
NSK	UKP	INA	RCJT
NTN	UKP	NSK	EWFL
KOYO	UKP	NTN	UELFL
SKF	SYFJ.RM	KOYO	NAFL
NSK	UBPA	SKF	FYTJ.KF
NTN	ASUP	NSK	UKFL
KOYO	SBPA	NTN	UKFL
SKF	SYFJ.TF	KOYO	UKFL
NSK	UCPA	SKF	FYC.RM
NTN	UCUP	NSK	UBFC
KOYO	UCPA	NTN	ASFC
SKF	SYFJ.FM	KOYO	SBFC
NTN	AELUP	SKF	FYC.TF
KOYO	SAPA	NSK	UCFC
SKF	SYFJ.WF	NTN	UCFC
NSK	EWPA	коуо	UCFC
NTN	UELUP	SKF	FYC.FM
KOYO	NAPA	NTN	AELFC
SKF	SYF.RM	SKF	FYC.WF
INA	PSHEY	INA	RFE
SKF	SYF TF	NSK	EWFC
INA	RSHEY	NTN	UELFC
•		· · ·	<u>322. 3</u>





Bearings

INTERCHANGE		INTERCHANGE	
KOYO	<u>NAFC</u>	NSK	<u>ENPFL</u>
SKF	FYC.KF	SKF	PFT.FM
NSK	<u>UKFC</u>	INA	RAT
NTN	UKFC	NTN	AELPFL
KOYO	<u>UKFC</u>	KOYO	SAPFL
SKF	TU.RM_	SKF	PFT.WF
NSK	<u>UBT</u>	INA	RRT
NTN	<u>AST</u>	SKF	<u>P.RM</u>
KOYO	<u>SBT</u>	INA	<u>PBY</u>
SKF	<u>TU.TF</u>	NSK	<u>UBPP</u>
NSK	<u>UCT</u>	NTN	<u>ASPP</u>
NTN	<u>UCT</u>	KOYO	SBPP
KOYO	<u>UCT</u>	SKF	<u>P TF</u>
SKF	<u>TU.FM</u>	SKF	P.WF
INA	PTUE	FAG	<u>SB762.B</u>
NSK	ENT	FKL	<u>UYS</u>
NTN	<u>AELT</u>	FKL	<u>UYF</u>
КОУО	SAT	FKL	LEC
SKF	<u>TU.WF</u>	FKL	LYC
INA	RTUE	SKF	SYJ.FM_
NSK	<u>EWT</u>	FAG	SG162
NTN	<u>UELT</u>	INA	PASE
KOYO	<u>NAT</u>	NSK	<u>ENP</u>
SKF	TU.KF	КОҮО	SAP
NSK	<u>UKT</u>	SKF	<u>FYJ.FM</u>
NTN	<u>UKT</u>	FAG	FG162
KOYO	<u>UKT</u>	INA	<u>PCJ</u>
SKF	PF.RM	NTN	AELF
INA	RAY	KOYO	SAF
NSK	UBPF	SKF	PF TF
NTN	ASPF	FAG	FB562
KOYO	SBPF FD763 B	INA	RRY
FAG	FB762.B	SKF	PF.WF
SKF	PFD.RM	FAG	FB362.B
INA	<u>PATRY</u>	INA	RR
SKF	PFD.TF		
INA	RRTRY		
SKF	PFD.FM		
INA SKF	RATR DED WE		
	PFD.WF		
INA SKF	RRTR DET DM		
INA	PFT.RM RATY		
NSK	UBPFL		
NTN	ASPFL		
KOYO	SBPFL		
SKF	PFT TF		
INA	RRTY		
UVA	<u>WWTT</u>		

