

LKU... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	<u>FKL</u>
INTERCHANGE	
FAG	<u>-</u>
NTN	<u>-</u>
INA	
NSK	<u>-</u>
SKF	SYF.KF
KOYO	<u></u>
FKL	<u>UES</u>
FKL	<u>UYS</u>
FKL	<u>USS</u>
FKL	LKS
FKL	UEV
FKL	LEV
FKL	<u>UYV</u>
FKL	<u>LYV</u>
FKL	<u>USV</u>
FKL	<u>LKV</u>
FKL	<u>UEU</u>
FKL	<u>LEU</u>
FKL	<u>UYU</u>
FKL	LYU
FKL	<u>USU</u>

INTERCHANGE	
FKL	UYF
FKL	USF
FKL	LKF
FKL	UEN
FKL	LEN
FKL	UYN
FKL	LYN
FKL	USN
FKL	LKN
FKL	UEG
FKL	LEG
FKL	UYG
FKL	LYG
FKL	USG
FKL	LKG
FKL	UET
FKL	<u>LET</u>
FKL	UYT
FKL	<u>LYT</u>
FKL	UST
FKL	<u>LKT</u>
FKL	UEC
FKL	<u>LEC</u>
FKL	LYC





Bearings

INTERCHANGE		INTERCHANGE	
FKL	USC	NSK	EWPA
FKL	LKC	NTN	UELUP
FKL	UED	KOYO	NAPA
FKL	LED	SKF	SYFJ.KF
FKL	UYD	NSK	UKPA
FKL	LYD	NTN	UKUP
FKL	USD	KOYO	<u>UKPA</u>
FKL	LKD	SKF	SYF.RM
FKL	UEP	INA	<u>PSHEY</u>
FKL	LEP	SKF	SYF TF
FKL	UYP	INA	RSHEY
FKL	LYP	SKF	SYF.FM
FKL	<u>USP</u>	INA	<u>PSHE</u>
FKL	LKP	SKF	SYF.WF
FKL	UER	INA	<u>RSHE</u>
FKL	LER	SKF	FYJ.FM
FKL	LYR	FAG	FG162
FKL	USR	INA	PCJ
FKL	LKR	NTN	<u>AELF</u>
SKF	SYJ.RM	KOYO	SAF
INA	PASEY	FAG	FG762.B
NSK	<u>UBP</u>	SKF	FYJ.KF
NTN	<u>ASP</u>	NSK	<u>UKF</u>
KOYO	SBP	NTN	<u>UKF</u>
SKF	SYJ.FM	KOYO	<u>UKF</u>
FAG	SG162	SKF	FYTJ.RM
INA	<u>PASE</u>	INA	<u>PCJTY</u>
NSK	<u>ENP</u>	NSK	<u>UBFL</u>
KOYO	SAP	NTN	<u>ASFL</u>
SKF	<u>-</u>	KOYO	<u>SBFL</u>
FAG	SG762.B	SKF	<u>FYTJ.TF</u>
KOYO	<u>-</u>	INA	RCJTY
SKF	SYJ.KF	NSK	<u>UCLF</u>
NSK	<u>UKP</u>	NTN	<u>UCFL</u>
NTN	<u>UKP</u>	KOYO	<u>UCFL</u>
KOYO	<u>UKP</u>	SKF	FYTJ.FM_
SKF	SYFJ.RM_	INA	<u>PCJT</u>
NSK	<u>UBPA</u>	NTN	<u>AELFL</u>
NTN	<u>ASUP</u>	KOYO	SAFL
KOYO	<u>SBPA</u>	SKF	<u>FYTJ.WF</u>
SKF	SYFJ.TF	INA	<u>RCJT</u>
NSK	<u>UCPA</u>	NSK	<u>EWFL</u>
NTN	<u>UCUP</u>	NTN	<u>UELFL</u>
KOYO	<u>UCPA</u>	KOYO	<u>NAFL</u>
SKF	SYFJ.FM	SKF	<u>FYTJ.KF</u>
NTN	AELUP	NSK	<u>UKFL</u>
KOYO	SAPA	NTN	<u>UKFL</u>
SKF	SYFJ.WF	KOYO	<u>UKFL</u>





Bearings

INTERCHANGE		INTERCHANGE	
SKF	FYC.RM	INA	RRY
NSK	<u>UBFC</u>	SKF	PF.WF
NTN	<u>ASFC</u>	FAG	FB362.B
KOYO	SBFC	INA	RR
SKF	FYC.TF	FAG	FB762.B
NSK	UCFC	SKF	PFD.RM
NTN	<u>UCFC</u>	INA	PATRY
KOYO	<u>UCFC</u>	SKF	PFD.TF
SKF	FYC.FM	INA	RRTRY
NTN	<u>AELFC</u>	SKF	PFD.FM
SKF	FYC.WF	INA	RATR
INA	RFE	SKF	PFD.WF
NSK	<u>EWFC</u>	INA	RRTR
NTN	<u>UELFC</u>	SKF	PFT.RM
KOYO	<u>NAFC</u>	INA	RATY
SKF	FYC.KF	NSK	<u>UBPFL</u>
NSK	<u>UKFC</u>	NTN	ASPFL
NTN	<u>UKFC</u>	KOYO	SBPFL
KOYO	<u>UKFC</u>	SKF	PFT TF
SKF	TU.RM	INA	RRTY
NSK	<u>UBT</u>	NSK	ENPFL
NTN	<u>AST</u>	SKF	PFT.FM
KOYO	<u>SBT</u>	INA	RAT
SKF	TU.TF	NTN	<u>AELPFL</u>
NSK	<u>UCT</u>	KOYO	SAPFL
NTN	<u>UCT</u>	SKF	PFT.WF
KOYO	<u>UCT</u>	INA	<u>RRT</u>
SKF	TU.FM_	SKF	P.RM_
INA	PTUE	INA	PBY
NSK	ENT	NSK	<u>UBPP</u>
NTN	<u>AELT</u>	NTN	<u>ASPP</u>
KOYO	SAT	KOYO	SBPP
SKF	TU.WF	SKF	P TF
INA	RTUE	SKF	P.WF
NSK	<u>EWT</u>	FAG	<u>SB762.B</u>
NTN	<u>UELT</u>		
KOYO	NAT		
SKF	TU.KF		
NSK	<u>UKT</u>		
NTN	<u>UKT</u>		
KOYO	<u>UKT</u>		
SKF	PF.RM		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	<u>ASPF</u>		
KOYO	SBPF		
SKF	PF TF		
FAG	FB562		

