



FG162 FAG

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FAG	INTERCHANGE	
		FKL	LEC
		FKL	LYC
FKL	<u>UYF</u>	FKL	<u>USC</u>
NSK	-	FKL	<u>LKC</u>
SKF	<u>FYJ.FM</u>	FKL	<u>UED</u>
INA	PCJ	FKL	LED
NTN	AELF	FKL	UYD
КОҮО	<u>SAF</u>	FKL	LYD
FKL	<u>USS</u>	FKL	USD
FKL	<u>UYV</u>	FKL	LKD
FKL	<u>USV</u>	FKL	UYP
FKL	<u>UEU</u>	FKL	LYP
FKL	<u>LEU</u>	FKL	USP
FKL	<u>UYU</u>	FKL	LKP
FKL	<u>LYU</u>	FKL	LER
FKL	<u>USU</u>	FKL	LYR
FKL	<u>LKU</u>	FKL	USR
FKL	<u>USF</u>	FKL	LKR
FKL	<u>UYN</u>	NTN	
FKL	<u>USN</u>	SKF	-
FKL	<u>UYG</u>	FAG	<u>SG762.B</u>
FKL	<u>USG</u>	INA	
FKL	<u>UST</u>	KOYO	
		FAG	-





Bearings

INTERCHANGE		INTERCHANGE	
SKF	SYFJ.FM	FKL	<u>LEV</u>
NTN	AELUP	FKL	LYV
КОҮО	<u>SAPA</u>	FKL	<u>LKV</u>
SKF	SYF.RM	FKL	LKF
INA	PSHEY	FKL	<u>UEN</u>
SKF	SYF TF	FKL	LEN
INA	<u>RSHEY</u>	FKL	<u>LYN</u>
SKF	SYF.FM	FKL	LKN
INA	<u>PSHE</u>	FKL	<u>UEG</u>
SKF	SYF.WF	FKL	LEG
INA	RSHE	FKL	<u>LYG</u>
SKF	SYF.KF	FKL	LKG
КОҮО		FKL	UET
FAG	FG762.B	FKL	LET
SKF	FYTJ.FM	FKL	 UYT
INA	PCJT	FKL	LYT
NTN	AELFL	FKL	LKT
КОҮО	SAFL	FKL	UEC
SKF	FYC.FM	FKL	UEP
NTN	AELFC	FKL	LEP
SKF	PF TF	FKL	UER
FAG	 FB562	SKF	SYJ.RM
INA	RRY	INA	PASEY
SKF	PF.WF	NSK	UBP
FAG	FB362.B	NTN	ASP
INA	RR	КОҮО	SBP
FAG	FB762.B	SKF	SYJ.FM
SKF	PFD.RM	FAG	SG162
INA	PATRY	INA	PASE
SKF	PFD.TF	NSK	ENP
INA	RRTRY	КОҮО	SAP
SKF	PFD.FM	SKF	SYJ.KF
INA	RATR	NSK	UKP
SKF	PFD.WF	NTN	UKP
INA	RRTR	КОҮО	UKP
SKF	PFT.FM	SKF	SYFJ.RM
INA	RAT	NSK	UBPA
NTN	AELPFL	NTN	ASUP
КОҮО	SAPFL	КОҮО	SBPA
SKF	PFT.WF	SKF	SYFJ.TF
INA	RRT	NSK	UCPA
SKF	P TF	NTN	UCUP
SKF	P.WF	KOYO	UCPA
FAG	SB762.B	SKF	SYFJ.WF
FKL	UES	NSK	
			<u>EWPA</u>
FKL	<u>UYS</u>	NTN	UELUP
FKL	<u>LKS</u>	KOYO	NAPA
FKL	<u>UEV</u>	SKF	<u>SYFJ.KF</u>





Bearings

INTERCHANGE		INTERCHANGE	
NSK	UKPA	NSK	UCT
NTN	UKUP	NTN	UCT
КОҮО	UKPA	КОҮО	UCT
SKF	FYJ.KF	SKF	TU.FM
NSK	UKF	INA	PTUE_
NTN	UKF	NSK	ENT
КОҮО	<u>UKF</u>	NTN	AELT
SKF	FYTJ.RM	КОҮО	SAT
INA	PCJTY	SKF	TU.WF
NSK	UBFL	INA	RTUE
NTN	ASFL	NSK	EWT
КОҮО	<u>SBFL</u>	NTN	UELT
SKF	<u>FYTJ.TF</u>	КОҮО	NAT
INA	RCJTY	SKF	TU.KF
NSK	UCLF	NSK	UKT
NTN	UCFL	NTN	UKT
КОҮО	UCFL	КОҮО	UKT
SKF	FYTJ.WF	SKF	PF.RM
INA	RCJT	INA	<u>RAY</u>
NSK	EWFL	NSK	UBPF
NTN	UELFL	NTN	ASPF_
КОҮО	NAFL	КОҮО	SBPF
SKF	FYTJ.KF	SKF	PFT.RM
NSK	UKFL	INA	RATY
NTN	<u>UKFL</u>	NSK	UBPFL
КОҮО	UKFL	NTN	ASPFL
SKF	FYC.RM	КОҮО	<u>SBPFL</u>
NSK	UBFC	SKF	PFT TF
NTN	ASFC	INA	RRTY
КОҮО	<u>SBFC</u>	NSK	ENPFL
SKF	FYC.TF	SKF	P.RM
NSK	UCFC	INA	PBY
NTN	UCFC	NSK	UBPP
КОҮО	UCFC	NTN	ASPP
SKF	FYC.WF	КОҮО	<u>SBPP</u>
INA	<u>RFE</u>		
NSK	EWFC		
NTN	UELFC		
КОҮО	NAFC		
SKF	FYC.KF		
NSK	<u>UKFC</u>		
NTN	UKFC		
КОҮО	UKFC		
SKF	TU.RM		
NSK	<u>UBT</u>		
NTN	AST		
КОҮО	<u>SBT</u>		
SKF	TU.TF		

