



FG762.B FAG

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FAG	INTERCHANGE	
		FKL	<u>UYF</u>
		FKL	<u>LKF</u>
FKL	<u>USF</u>	FKL	<u>UYN</u>
NTN	-	FKL	<u>USN</u>
SKF	<u> </u>	FKL	<u>LKN</u>
INA	<u>-</u>	FKL	<u>UEG</u>
NSK		FKL	<u>LEG</u>
KOYO	-	FKL	<u>UYG</u>
FKL	<u>UYS</u>	FKL	<u>USG</u>
FKL	<u>USS</u>	FKL	<u>LKG</u>
FKL	<u>LKS</u>	FKL	<u>UET</u>
FKL	<u>UEV</u>	FKL	LET
FKL	<u>LEV</u>	FKL	<u>UST</u>
FKL	<u>UYV</u>	FKL	<u>LKT</u>
FKL	<u>LYV</u>	FKL	<u>LEC</u>
FKL	<u>USV</u>	FKL	LYC
FKL	<u>LKV</u>	FKL	<u>USC</u>
FKL	<u>UEU</u>	FKL	LKC
FKL	<u>LEU</u>	FKL	<u>UED</u>
FKL	<u>UYU</u>	FKL	<u>LED</u>
FKL	<u>LYU</u>	FKL	<u>UYD</u>
FKL	<u>USU</u>	FKL	LYD
FKL	<u>LKU</u>	FKL	<u>USD</u>
		FKL	<u>LKD</u>





Bearings

INTERCHANGE		INTERCHANGE	
FKL	<u>LEP</u>	КОҮО	
FKL	UYP	SKF	FYJ.FM
FKL	<u>LYP</u>	FAG	FG162
FKL	USP	INA	PCJ_
FKL	<u>LKP</u>	NTN	AELF
FKL	LER	КОҮО	SAF
FKL	<u>LYR</u>	SKF	<u>FYJ.KF</u>
FKL	USR	NSK	UKF
FKL	<u>LKR</u>	NTN	<u>UKF</u>
SKF	SYJ.FM	КОҮО	UKF
FAG	SG162	SKF	<u>FYTJ.FM</u>
INA	PASE	INA	PCJT
NSK	ENP	NTN	AELFL
КОҮО	SAP	КОҮО	SAFL
FAG	SG762.B	SKF	FYTJ.KF
FAG	-	NSK	UKFL
SKF	SYJ.KF	NTN	UKFL
NSK	UKP	КОҮО	UKFL
NTN	UKP	SKF	FYC.RM
КОҮО	UKP	NSK	UBFC
SKF	SYFJ.RM	NTN	ASFC
NSK	UBPA	КОҮО	SBFC
NTN	ASUP	SKF	FYC.TF
коүо	SBPA	NSK	UCFC
SKF	SYFJ.TF	NTN	UCFC
NSK	UCPA	КОҮО	UCFC
NTN	UCUP	SKF	FYC.FM
коүо	UCPA	NTN	AELFC
SKF	SYFJ.FM	SKF	FYC.KF
NTN	AELUP	NSK	UKFC
КОҮО	SAPA	NTN	UKFC
SKF	SYFJ.WF	КОҮО	UKFC
NSK	EWPA	SKF	TU.RM
NTN	UELUP	NSK	UBT
КОҮО	NAPA	NTN	AST
SKF	SYFJ.KF	КОҮО	SBT
NSK	UKPA	SKF	TU.TF
NTN	UKUP	NSK	UCT
КОҮО	UKPA	NTN	UCT
SKF	SYF.RM	КОҮО	UCT
INA	PSHEY	SKF	TU.KF
SKF	SYF TF	NSK	UKT
INA	RSHEY	NTN	UKT
SKF	SYF.FM	КОҮО	
INA	PSHE	SKF	PF TF
SKF	SYF.WF	FAG	FB562
INA	<u>RSHE</u>	INA	RRY
SKF	SYF.KF	SKF	PF.WF
	<u>511.IXI</u>		<u>1 1 . VVI</u>





Bearings

INTERCHANGE		INTERCHANGE	
FAG	FB362.B	SKF	<u>FYTJ.WF</u>
INA	RR	INA	<u>RCJT</u>
FAG	FB762.B	NSK	EWFL
SKF	PFD.RM	NTN	UELFL
INA	PATRY	КОҮО	NAFL
SKF	PFD.TF	SKF	FYC.WF
INA	RRTRY	INA	<u>RFE</u>
SKF	PFD.FM	NSK	EWFC
INA	RATR	NTN	<u>UELFC</u>
SKF	PFD.WF	КОҮО	NAFC
INA	RRTR	SKF	TU.FM
SKF	PFT TF	INA	PTUE
INA	<u>RRTY</u>	NSK	ENT
NSK	ENPFL	NTN	AELT
SKF	PFT.FM	КОҮО	<u>SAT</u>
INA	RAT	SKF	TU.WF
NTN	AELPFL	INA	<u>RTUE</u>
КОҮО	SAPFL	NSK	EWT
SKF	PFT.WF	NTN	<u>UELT</u>
INA	RRT	КОҮО	NAT
SKF	<u>P TF</u>	SKF	PF.RM
SKF	P.WF	INA	RAY
FAG	<u>SB762.B</u>	NSK	<u>UBPF</u>
FKL	<u>UES</u>	NTN	ASPF
FKL	<u>UEN</u>	КОҮО	<u>SBPF</u>
FKL	<u>LEN</u>	SKF	PFT.RM
FKL	<u>LYN</u>	INA	RATY
FKL	<u>LYG</u>	NSK	UBPFL
FKL	<u>UYT</u>	NTN	ASPFL
FKL	<u>LYT</u>	КОҮО	<u>SBPFL</u>
FKL	<u>UEC</u>	SKF	P.RM
FKL	<u>UEP</u>	INA	PBY
FKL	<u>UER</u>	NSK	UBPP
SKF	SYJ.RM	NTN	ASPP
INA	PASEY	КОҮО	<u>SBPP</u>
NSK	<u>UBP</u>		
NTN	ASP		
КОҮО	<u>SBP</u>		
SKF	FYTJ.RM		
INA	<u>PCJTY</u>		
NSK	UBFL		
NTN	ASFL		
КОҮО	<u>SBFL</u>		
SKF	<u>FYTJ.TF</u>		
INA	<u>RCJTY</u>		
NSK	UCLF		
NTN	UCFL		
КОҮО	UCFL		

