



## **SBFL KOYO**

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



## **Technical specification**

MANUFACTURER	KOYO	INTERCHANGE	
		FKL	<u>UYN</u>
		FKL	<u>LYN</u>
FKL	<u>UEN</u>	FKL	<u>USN</u>
FAG	-	FKL	LKN
SKF	FYTJ.RM	FKL	<u>UEG</u>
INA	<u>PCJTY</u>	FKL	LEG
NSK	UBFL	FKL	UYG
NTN	ASFL	FKL	LYG
FKL	<u>UES</u>	FKL	USG
FKL	<u>LKS</u>	FKL	LKG
FKL	<u>UEV</u>	FKL	UET
FKL	<u>UYV</u>	FKL	LET
FKL	<u>LYV</u>	FKL	UYT
FKL	<u>USV</u>	FKL	LYT
FKL	<u>LKV</u>	FKL	UST
FKL	<u>UEU</u>	FKL	<u>LKT</u>
FKL	<u>LEU</u>	FKL	UEC
FKL	<u>UYU</u>	FKL	LKC
FKL	<u>LYU</u>	FKL	UED
FKL	<u>USU</u>	FKL	<u>LED</u>
FKL	<u>LKU</u>	FKL	
FKL	LKF		UYD
FKL	LEN	FKL	LYD
		FKL	<u>USD</u>
		FKL	<u>LKD</u>





## Bearings

INTERCHANGE		INTERCHANGE	
FKL	<u>UEP</u>	SKF	<u>FYJ.KF</u>
FKL	LEP	NSK	UKF
FKL	<u>UYP</u>	NTN	UKF
FKL	<u>LYP</u>	КОҮО	UKF
FKL	<u>USP</u>	SKF	<u>FYTJ.TF</u>
FKL	UER	INA	<u>RCJTY</u>
FKL	<u>LER</u>	NSK	UCLF
FKL	LYR	NTN	UCFL
FKL	<u>LKR</u>	КОҮО	UCFL
SKF	SYJ.RM	SKF	FYTJ.FM
INA	PASEY	INA	PCJT_
NSK	UBP	NTN	AELFL
NTN	ASP	КОҮО	SAFL
КОҮО	SBP	SKF	FYTJ.WF
INA	-	INA	RCJT
SKF	SYJ.KF	NSK	EWFL
NSK	UKP	NTN	UELFL
NTN	UKP	КОҮО	NAFL
КОҮО	UKP	SKF	FYTJ.KF
SKF	SYFJ.RM	NSK	UKFL
NSK	UBPA	NTN	UKFL
NTN	ASUP	КОҮО	UKFL
КОҮО	SBPA	SKF	FYC.RM
NSK	-	NSK	UBFC
SKF	SYFJ.FM	NTN	ASFC
NTN	AELUP	КОҮО	SBFC
коуо	SAPA	SKF	FYC.TF
SKF	SYFJ.WF	NSK	UCFC
NSK	EWPA	NTN	UCFC
NTN	UELUP	КОҮО	UCFC
КОҮО	NAPA	SKF	FYC.FM
NTN	-	NTN	AELFC
SKF	-	SKF	FYC.WF
коуо	-	INA	RFE
SKF		NSK	EWFC
NSK	UKPA	NTN	UELFC
NTN	UKUP	КОҮО	NAFC
КОҮО	UKPA	SKF	FYC.KF
SKF	SYF.RM	NSK	UKFC
INA	PSHEY	NTN	UKFC
SKF		КОҮО	
INA	SYF TF	SKF	UKFC
SKF	<u>RSHEY</u>	NSK	TU.RM
	SYF.FM		UBT
INA	PSHE	NTN	AST
SKF	SYF.WF	KOYO	<u>SBT</u>
INA	<u>RSHE</u>	SKF	<u>TU.TF</u>
SKF	<u>SYF.KF</u>	NSK	UCT
КОҮО		NTN	UCT





## Bearings

INTERCHANGE		INTERCHANGE	
КОҮО	UCT	SKF	P.WF
SKF	TU.FM	FKL	<u>UYS</u>
INA	PTUE	FKL	<u>USS</u>
NSK	ENT	FKL	LEV
NTN	AELT	FKL	<u>UYF</u>
КОҮО	SAT	FKL	USF
SKF	TU.WF	FKL	LEC
INA	RTUE	FKL	LYC
NSK	EWT	FKL	<u>USC</u>
NTN	UELT	FKL	<u>LKP</u>
КОҮО	NAT	FKL	<u>USR</u>
SKF	TU.KF	SKF	SYJ.FM
NSK	<u>UKT</u>	FAG	<u>SG162</u>
NTN	UKT	INA	PASE
КОҮО	UKT	NSK	ENP
SKF	PF.RM	КОҮО	SAP
INA	RAY	FAG	<u>SG762.B</u>
NSK	UBPF	SKF	SYFJ.TF
NTN	ASPF	NSK	UCPA
КОҮО	SBPF	NTN	UCUP
SKF	PFD.RM	КОҮО	UCPA
INA	PATRY	SKF	FYJ.FM
SKF	PFD.TF	FAG	FG162
INA	RRTRY	INA	PCJ
SKF	PFD.FM	NTN	AELF
INA	RATR	КОҮО	SAF
SKF	PFD.WF	FAG	FG762.B
INA	RRTR	SKF	PF TF
SKF	PFT.RM	FAG	FB562
INA	RATY	INA	<u>RRY</u>
NSK	<u>UBPFL</u>	SKF	PF.WF
NTN	ASPFL	FAG	FB362.B
КОҮО	<u>SBPFL</u>	INA	<u>RR</u>
SKF	PFT TF	FAG	FB762.B
INA	<u>RRTY</u>	FAG	<u>SB762.B</u>
NSK	ENPFL		
SKF	PFT.FM		
INA	RAT		
NTN	AELPFL		
КОҮО	<u>SAPFL</u>		
SKF	PFT.WF		
INA	<u>RRT</u>		
SKF	P.RM		
INA	<u>PBY</u>		
NSK	UBPP		
NTN	ASPP		
КОҮО	<u>SBPP</u>		
SKF	<u>P TF</u>		

