

PCJT INA

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	INA	INTERCHANGE	
		FKL	<u>USF</u>
		FKL	<u>LKF</u>
FKL	<u>UYN</u>	FKL	<u>UEN</u>
FAG	-	FKL	LEN
NSK	<u>-</u>	FKL	LYN
SKF	<u>FYTJ.FM</u>	FKL	USN
NTN	AELFL	FKL	LKN
КОҮО	SAFL	FKL	UEG
FKL	<u>UES</u>	FKL	LEG
FKL	<u>USS</u>	FKL	UYG
FKL	<u>LKS</u>	FKL	LYG
FKL	<u>UEV</u>	FKL	USG
FKL	<u>UYV</u>	FKL	LKG
FKL	<u>LYV</u>	FKL	UET
FKL	<u>USV</u>	FKL	LET
FKL	<u>LKV</u>	FKL	<u>UYT</u>
FKL	<u>UEU</u>	FKL	<u>LYT</u>
FKL	<u>LEU</u>	FKL	UST
FKL	<u>UYU</u>	FKL	LKT
FKL	LYU	FKL	<u>UEC</u>
FKL	<u>USU</u>	FKL	
FKL	LKU		LEC
FKL	UYF	FKL	LYC
		FKL	<u>USC</u>
		FKL	<u>LKC</u>





Bearings

INTERCHANGE		INTERCHANGE	
FKL	UED	SKF	SYF TF
FKL	LED	INA	RSHEY
FKL	UYD	SKF	SYF.FM
FKL	LYD	INA	PSHE
FKL	USD	SKF	SYF.WF
FKL	LKD	INA	RSHE
FKL	UEP	SKF	SYF.KF
FKL	LEP	КОҮО	
FKL	UYP	SKF	FYJ.FM
FKL	LYP	FAG	FG162
FKL	USP	INA	PCJ
FKL	LKP	NTN	AELF
FKL	UER	КОҮО	SAF
FKL	LER	FAG	FG762.B
FKL	LYR	SKF	FYJ.KF
FKL	USR	NSK	UKF
FKL	LKR	NTN	UKF
SKF	SYJ.RM	КОҮО	UKF
INA	PASEY	SKF	FYTJ.RM
NSK	UBP	INA	PCJTY
NTN	ASP	NSK	UBFL
коүо	SBP	NTN	ASFL
NTN	-	КОҮО	SBFL
SKF	-	SKF	FYTJ.TF
FAG	SG762.B	INA	RCJTY
INA	-	NSK	UCLF
КОҮО	-	NTN	UCFL
SKF	SYJ.KF	КОҮО	UCFL
NSK	UKP	SKF	FYTJ.WF
NTN	UKP	INA	RCJT
КОҮО	UKP	NSK	EWFL
SKF	SYFJ.RM	NTN	UELFL
NSK	UBPA	КОҮО	NAFL
NTN	ASUP	SKF	FYTJ.KF
КОҮО	SBPA	NSK	UKFL
SKF	SYFJ.FM	NTN	UKFL
NTN	AELUP	КОҮО	UKFL
коүо	SAPA	SKF	FYC.RM
SKF	SYFJ.WF	NSK	UBFC
NSK	EWPA	NTN	ASFC
NTN	UELUP	КОҮО	SBFC
коуо	NAPA	SKF	FYC.TF
SKF	SYFJ.KF	NSK	UCFC
NSK	UKPA	NTN	UCFC
NTN	UKUP	КОҮО	UCFC
КОҮО	UKPA	SKF	FYC.FM
SKF	SYF.RM	NTN	AELFC
INA	PSHEY	SKF	FYC.WF





Bearings

INTERCHANGE		INTERCHANGE	
INA	<u>RFE</u>	SKF	PFD.WF
NSK	EWFC	INA	<u>RRTR</u>
NTN	<u>UELFC</u>	SKF	PFT.RM
КОҮО	NAFC	INA	RATY
SKF	FYC.KF	NSK	<u>UBPFL</u>
NSK	UKFC	NTN	ASPFL
NTN	<u>UKFC</u>	КОҮО	<u>SBPFL</u>
КОҮО	UKFC	SKF	<u>PFT TF</u>
SKF	TU.RM	INA	<u>RRTY</u>
NSK	<u>UBT</u>	NSK	<u>ENPFL</u>
NTN	AST	SKF	PFT.FM
КОҮО	<u>SBT</u>	INA	RAT
SKF	TU.TF	NTN	AELPFL
NSK	UCT	КОҮО	<u>SAPFL</u>
NTN	UCT	SKF	PFT.WF
КОҮО	UCT	INA	<u>RRT</u>
SKF	TU.FM	SKF	P.RM_
INA	PTUE	INA	<u>PBY</u>
NSK	<u>ENT</u>	NSK	<u>UBPP</u>
NTN	<u>AELT</u>	NTN	ASPP
КОҮО	<u>SAT</u>	КОҮО	<u>SBPP</u>
SKF	TU.WF	SKF	<u>P TF</u>
INA	RTUE	SKF	P.WF
NSK	<u>EWT</u>	FAG	<u>SB762.B</u>
NTN	UELT	FKL	<u>UYS</u>
коуо	NAT	FKL	<u>LEV</u>
SKF	<u>TU.KF</u>	SKF	<u>SYJ.FM</u>
NSK	UKT	FAG	<u>SG162</u>
NTN	UKT	INA	PASE
КОҮО	<u>UKT</u>	NSK	<u>ENP</u>
SKF	PF.RM	KOYO	SAP
INA	RAY	SKF	SYFJ.TF
NSK	UBPF	NSK	UCPA
NTN	ASPF	NTN	UCUP
КОҮО	<u>SBPF</u>	KOYO	<u>UCPA</u>
SKF	PF TF		
FAG	FB562		
INA SKF	RRY PF.WF		
FAG	FB362.B		
INA			
FAG	<u>RR</u> FB762.B		
SKF	PFD.RM		
INA	PATRY		
SKF	PFD.TF		
INA	RRTRY		
SKF	PFD.FM		
INA	RATR		

