USF... LKF... UEN... LEN... UYN... LYN... USN... LKN... LEG... UYG... LYG... USG... LKG... UET... LET... UYT... LYT... UST... LKT... UEC... USC... LKC... UED... LED...



UEG... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FKL	INTERCHANGE
		FKL
INTERCHANGE		FKL
FAG	<u>-</u>	FKL
INA	<u>-</u>	FKL
SKF	FYC.RM	FKL
NSK	<u>UBFC</u>	FKL
NTN	<u>ASFC</u>	FKL
KOYO	<u>SBFC</u>	FKL
FKL	<u>UES</u>	FKL
FKL	<u>USS</u>	FKL
FKL	<u>LKS</u>	FKL
FKL	<u>UEV</u>	FKL
FKL	<u>LEV</u>	FKL
FKL	<u>UYV</u>	FKL
FKL	<u>LYV</u>	FKL
FKL	USV	FKL
FKL	<u>LKV</u>	FKL
FKL	UEU	FKL
FKL	LEU	FKL
FKL	UYU	FKL
FKL	LYU	
FKL	USU	FKL
FKL	LKU	FKL
		FKL
		FKL





Bearings

INTERCHANGE		INTERCHANGE	
FKL	UYD	SKF	SYF.RM
FKL	LYD	INA	PSHEY
FKL	USD	SKF	SYF TF
FKL	LKD	INA	RSHEY
FKL	UEP	SKF	SYF.FM
FKL	LEP	INA	PSHE
FKL	UYP	SKF	SYF.WF
FKL	LYP	INA	RSHE
FKL	USP	SKF	SYF.KF
FKL	LKP	KOYO	
FKL	UER	FAG	FG762.B
FKL	LER	SKF	FYJ.KF
FKL	LYR	NSK	UKF
FKL	USR	NTN	UKF
FKL	LKR	KOYO	UKF
SKF	SYJ.RM	SKF	FYTJ.RM
INA	PASEY	INA	PCJTY
NSK	UBP	NSK	UBFL
NTN	ASP	NTN	ASFL
KOYO	SBP	KOYO	SBFL
NTN	-	SKF	FYTJ.TF
SKF	-	INA	RCJTY
FAG	SG762.B	NSK	UCLF
NSK	-	NTN	UCFL
KOYO	-	KOYO	UCFL
SKF	SYJ.KF	SKF	FYTJ.FM
NSK	UKP	INA	PCJT
NTN	UKP	NTN	AELFL
KOYO	UKP	KOYO	SAFL
SKF	SYFJ.RM	SKF	FYTJ.WF
NSK	UBPA	INA	RCJT
NTN	ASUP	NSK	EWFL
KOYO	SBPA	NTN	UELFL
SKF	SYFJ.TF	KOYO	NAFL
NSK	<u>UCPA</u>	SKF	FYTJ.KF
NTN	UCUP	NSK	UKFL
KOYO	<u>UCPA</u>	NTN	<u>UKFL</u>
SKF	SYFJ.FM	KOYO	UKFL
NTN	<u>AELUP</u>	SKF	FYC.TF
KOYO	SAPA	NSK	UCFC
SKF	SYFJ.WF	NTN	<u>UCFC</u>
NSK	EWPA	коуо	<u>UCFC</u>
NTN	<u>UELUP</u>	SKF	FYC.FM
коуо	NAPA	NTN	AELFC
SKF	SYFJ.KF	SKF	FYC.WF
NSK	<u>UKPA</u>	INA	RFE
NTN	<u>UKUP</u>	NSK	<u>EWFC</u>
KOYO	UKPA	NTN	<u>UELFC</u>





Bearings

INTERCHANGE		INTERCHANGE	
KOYO	<u>NAFC</u>	NSK	<u>ENPFL</u>
SKF	FYC.KF	SKF	PFT.FM
NSK	<u>UKFC</u>	INA	RAT
NTN	UKFC	NTN	AELPFL
KOYO	<u>UKFC</u>	KOYO	SAPFL
SKF	TU.RM_	SKF	PFT.WF
NSK	<u>UBT</u>	INA	RRT
NTN	AST	SKF	P.RM
KOYO	SBT	INA	<u>PBY</u>
SKF	<u>TU.TF</u>	NSK	<u>UBPP</u>
NSK	<u>UCT</u>	NTN	<u>ASPP</u>
NTN	<u>UCT</u>	KOYO	SBPP
KOYO	<u>UCT</u>	SKF	<u>P TF</u>
SKF	TU.FM_	SKF	P.WF
INA	PTUE	FAG	<u>SB762.B</u>
NSK	<u>ENT</u>	FKL	UYS
NTN	AELT	FKL	<u>UYF</u>
KOYO	SAT	FKL	LEC
SKF	<u>TU.WF</u>	FKL	LYC
INA	RTUE	SKF	SYJ.FM_
NSK	<u>EWT</u>	FAG	SG162
NTN	<u>UELT</u>	INA	PASE
KOYO	NAT	NSK	<u>ENP</u>
SKF	<u>TU.KF</u>	KOYO	SAP
NSK	<u>UKT</u>	SKF	<u>FYJ.FM</u>
NTN	<u>UKT</u>	FAG	FG162
KOYO	<u>UKT</u>	INA	<u>PCJ</u>
SKF	PF.RM	NTN	AELF
INA	RAY	KOYO	SAF
NSK	UBPF	SKF	PF TF
NTN	<u>ASPF</u>	FAG	FB562
KOYO	SBPF 507.63 P	INA	RRY
FAG	FB762.B	SKF	PF.WF
SKF	PFD.RM	FAG	FB362.B
INA	<u>PATRY</u>	INA	RR
SKF	PFD.TF		
INA	RRTRY		
SKF	PFD.FM		
INA SKF	RATR DED WE		
	PFD.WF		
INA SKF	RRTR DET DM		
INA	PFT.RM RATY		
NSK	UBPFL		
NTN	ASPFL		
KOYO	SBPFL_		
SKF	PFT TF		
INA	RRTY		
IIVA	KKII		

