

UYG... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FKL	INTERCHANGE
INTERCHANCE		FKL
INTERCHANGE		FKL
FAG	<u>-</u>	FKL
INA	<u>-</u>	FKL
NSK	<u>-</u>	FKL
KOYO	<u>-</u>	FKL
SKF	FYC.FM	FKL
NTN	<u>AELFC</u>	FKL
FKL	UES	FKL
FKL	USS	FKL
FKL	LKS	FKL
FKL	UEV	FKL
FKL	LEV	
FKL	UYV	FKL
FKL	LYV	FKL
FKL	USV	FKL
FKL	LKV	FKL
FKL	UEU	FKL
FKL	LEU	FKL
FKL	<u>UYU</u>	FKL
FKL		FKL
	LYU	FKL
FKL	USU	FKL
FKL	<u>LKU</u>	FKL

INTERCHANGE	
FKL	UYF
FKL	USF
FKL	<u>LKF</u>
FKL	UEN
FKL	LEN
FKL	UYN
FKL	LYN
FKL	USN
FKL	LKN
FKL	<u>UEG</u>
FKL	LEG
FKL	LYG
FKL	USG
FKL	LKG
FKL	<u>UET</u>
FKL	<u>LET</u>
FKL	<u>UYT</u>
FKL	LYT
FKL	<u>UST</u>
FKL	<u>LKT</u>
FKL	<u>UEC</u>
FKL	<u>LEC</u>
FKL	LYC
FKL	USC





Bearings

INTERCHANGE		INTERCHANGE	
FKL	LKC	KOYO	UKPA
FKL	UED	SKF	SYF.RM
FKL	LED	INA	PSHEY
FKL	UYD	SKF	SYF TF
FKL	LYD	INA	RSHEY
FKL	USD	SKF	SYF.FM
FKL	LKD	INA	PSHE
FKL	UEP	SKF	SYF.WF
FKL	LEP	INA	RSHE
FKL	UYP	SKF	SYF.KF
FKL	LYP	KOYO	
FKL	USP	SKF	FYJ.FM
FKL	LKP	FAG	FG162
FKL	UER	INA	PCJ
FKL	LER	NTN	AELF
FKL	LYR	KOYO	SAF
FKL	USR	FAG	FG762.B
FKL	LKR	SKF	FYJ.KF
SKF	SYJ.RM	NSK	UKF
INA	PASEY	NTN	UKF
NSK	UBP	KOYO	UKF
NTN	ASP	SKF	FYTJ.RM
KOYO	SBP	INA	PCJTY
NTN	-	NSK	UBFL
SKF		NTN	ASFL
FAG	SG762.B	KOYO	SBFL
SKF	SYJ.KF	SKF	FYTJ.TF
NSK	UKP	INA	RCJTY
NTN	UKP	NSK	UCLF
KOYO	UKP	NTN	UCFL
SKF	SYFJ.RM	KOYO	UCFL
NSK	UBPA	SKF	FYTJ.FM
NTN	ASUP	INA	PCJT
KOYO	SBPA	NTN	AELFL
SKF	SYFJ.TF	KOYO	SAFL
NSK	UCPA	SKF	FYTJ.WF
NTN	UCUP	INA	RCJT
KOYO	UCPA	NSK	EWFL
SKF	SYFJ.FM	NTN	UELFL
NTN	AELUP	KOYO	NAFL
KOYO	SAPA	SKF	FYTJ.KF
SKF	SYFJ.WF	NSK	UKFL
NSK	EWPA	NTN	UKFL
NTN	UELUP	KOYO	UKFL
KOYO	NAPA	SKF	FYC.RM
SKF	SYFJ.KF	NSK	UBFC
NSK	UKPA	NTN	ASFC
NTN	UKUP	KOYO	SBFC
	<u> </u>		<u> </u>





Bearings

INTERCHANGE		INTERCHANGE	
SKF	FYC.TF	INA	<u>PATRY</u>
NSK	<u>UCFC</u>	SKF	PFD.TF
NTN	<u>UCFC</u>	INA	RRTRY
KOYO	<u>UCFC</u>	SKF	PFD.FM
SKF	FYC.WF	INA	RATR
INA	RFE	SKF	PFD.WF
NSK	<u>EWFC</u>	INA	RRTR
NTN	<u>UELFC</u>	SKF	PFT.RM
KOYO	NAFC	INA	RATY
SKF	FYC.KF	NSK	<u>UBPFL</u>
NSK	<u>UKFC</u>	NTN	<u>ASPFL</u>
NTN	UKFC	KOYO	SBPFL
KOYO	<u>UKFC</u>	SKF	PFT TF
SKF	<u>TU.RM</u>	INA	RRTY
NSK	<u>UBT</u>	NSK	<u>ENPFL</u>
NTN	AST	SKF	PFT.FM
KOYO	SBT	INA	RAT
SKF	<u>TU.TF</u>	NTN	AELPFL
NSK	<u>UCT</u>	KOYO	SAPFL
NTN	<u>UCT</u>	SKF	PFT.WF
KOYO	<u>UCT</u>	INA	RRT
SKF	TU.FM_	SKF	P.RM_
INA	PTUE	INA	<u>PBY</u>
NSK	ENT	NSK	<u>UBPP</u>
NTN	AELT	NTN	ASPP
KOYO	SAT	KOYO	SBPP
SKF	TU.WF	SKF	<u>P TF</u>
INA	RTUE	SKF	<u>P.WF</u>
NSK	<u>EWT</u>	FAG	SB762.B
NTN	UELT	FKL	UYS
KOYO	NAT	SKF	SYJ.FM
SKF	TU.KF	FAG	SG162
NSK	<u>UKT</u>	INA	PASE
NTN KOYO	<u>UKT</u> <u>UKT</u>	NSK KOYO	ENP SAP
SKF	PF.RM	K010	<u> SAP</u>
INA	RAY		
NSK	UBPF		
NTN	ASPF		
KOYO	SBPF		
SKF	PF TF		
FAG	FB562		
INA	RRY		
SKF	PF.WF		
FAG	FB362.B		
INA	RR		
FAG	FB762.B		
SKF	PFD.RM		

