

## ΝΑΤ ΚΟΥΟ

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



## **Technical specification**

MANUFACTURER	KOYO	INTERCHANGE	
		FKL	<u>LEN</u>
		FKL	<u>UYN</u>
FKL	<u>LYT</u>	FKL	LYN
FAG	<u> </u>	FKL	USN
SKF	TU.WF	FKL	<u>LKN</u>
INA	RTUE	FKL	UEG
NSK	EWT	FKL	LEG
NTN	<u>UELT</u>	FKL	UYG
FKL	<u>UES</u>	FKL	LYG
FKL	<u>LKS</u>	FKL	USG
FKL	<u>UEV</u>	FKL	LKG
FKL	<u>UYV</u>	FKL	UET
FKL	<u>LYV</u>	FKL	LET
FKL	<u>USV</u>	FKL	UYT
FKL	<u>LKV</u>	FKL	UST
FKL	<u>UEU</u>	FKL	LKT
FKL	<u>LEU</u>	FKL	UEC
FKL	<u>UYU</u>	FKL	LKC
FKL	<u>LYU</u>	FKL	UED
FKL	<u>USU</u>	FKL	LED
FKL	<u>LKU</u>	FKL	UYD
FKL	<u>LKF</u>	FKL	LYD
FKL	<u>UEN</u>	FKL	USD
		FKL	LKD





## Bearings

INTERCHANGE		INTERCHANGE	
FKL	UEP	SKF	FYJ.KF_
FKL	LEP	NSK	UKF
FKL	<u>UYP</u>	NTN	<u>UKF</u>
FKL	LYP	КОҮО	UKF
FKL	<u>USP</u>	SKF	<u>FYTJ.RM</u>
FKL	UER	INA	PCJTY
FKL	LER	NSK	<u>UBFL</u>
FKL	LYR	NTN	ASFL
FKL	<u>LKR</u>	КОҮО	<u>SBFL</u>
SKF	SYJ.RM	SKF	<u>FYTJ.TF</u>
INA	PASEY	INA	RCJTY_
NSK	UBP	NSK	UCLF
NTN	ASP	NTN	UCFL
КОҮО	SBP	КОҮО	UCFL
INA		SKF	FYTJ.FM
SKF	SYJ.KF	INA	PCJT
NSK	UKP	NTN	AELFL
NTN	UKP	КОҮО	SAFL
КОҮО	UKP	SKF	FYTJ.WF
SKF	SYFJ.RM	INA	RCJT
NSK	UBPA	NSK	EWFL
NTN	ASUP	NTN	UELFL
КОҮО	SBPA	КОҮО	NAFL
NSK	-	SKF	FYTJ.KF
SKF	SYFJ.FM	NSK	UKFL
NTN	AELUP	NTN	UKFL
КОҮО	SAPA	КОҮО	UKFL
SKF	SYFJ.WF	SKF	FYC.RM
NSK	EWPA	NSK	UBFC
NTN	UELUP	NTN	ASFC
КОҮО	NAPA	КОҮО	SBFC
NTN	-	SKF	FYC.TF
SKF	-	NSK	UCFC
коүо	-	NTN	UCFC
SKF	SYFJ.KF	КОҮО	UCFC
NSK	UKPA	SKF	FYC.FM
NTN	UKUP	NTN	AELFC
коүо	UKPA	SKF	FYC.WF
SKF	SYF.RM	INA	RFE
INA	PSHEY	NSK	EWFC
SKF	SYF TF	NTN	UELFC
INA	RSHEY	КОҮО	NAFC
SKF	SYF.FM	SKF	FYC.KF
INA	PSHE	NSK	UKFC
SKF	SYF.WF	NTN	UKFC
INA	RSHE	КОҮО	UKFC
SKF	SYF.KF	SKF	TU.RM
КОҮО		NSK	UBT





## Bearings

INTERCHANGE		INTERCHANGE	
NTN	AST	SKF	P.WF
КОҮО	<u>SBT</u>	FKL	<u>UYS</u>
SKF	<u>TU.TF</u>	FKL	<u>USS</u>
NSK	UCT	FKL	<u>LEV</u>
NTN	UCT	FKL	<u>UYF</u>
КОҮО	UCT	FKL	USF
SKF	TU.FM	FKL	LEC
INA	PTUE	FKL	LYC
NSK	ENT	FKL	<u>USC</u>
NTN	AELT	FKL	<u>LKP</u>
КОҮО	<u>SAT</u>	FKL	<u>USR</u>
SKF	TU.KF	SKF	<u>SYJ.FM</u>
NSK	<u>UKT</u>	FAG	<u>SG162</u>
NTN	UKT	INA	PASE
КОҮО	UKT	NSK	<u>ENP</u>
SKF	PF.RM	КОҮО	SAP
INA	RAY	FAG	<u>SG762.B</u>
NSK	UBPF	SKF	SYFJ.TF
NTN	ASPF	NSK	UCPA
КОҮО	SBPF	NTN	UCUP
SKF	PFD.RM	КОҮО	UCPA
INA	PATRY	SKF	<u>FYJ.FM</u>
SKF	PFD.TF	FAG	FG162
INA	RRTRY	INA	PCJ
SKF	PFD.FM	NTN	AELF
INA	RATR	КОҮО	SAF
SKF	PFD.WF	FAG	FG762.B
INA	RRTR	SKF	<u>PF TF</u>
SKF	PFT.RM	FAG	<u>FB562</u>
INA	RATY	INA	RRY
NSK	UBPFL	SKF	PF.WF
NTN	ASPFL	FAG	FB362.B
КОҮО	<u>SBPFL</u>	INA	RR
SKF	PFT TF	FAG	FB762.B
INA	<u>RRTY</u>	FAG	<u>SB762.B</u>
NSK	ENPFL		
SKF	PFT.FM		
INA	<u>RAT</u>		
NTN	AELPFL		
КОҮО	<u>SAPFL</u>		
SKF	PFT.WF		
INA	<u>RRT</u>		
SKF	P.RM		
INA	<u>PBY</u>		
NSK	<u>UBPP</u>		
NTN	ASPP		
КОҮО	<u>SBPP</u>		
SKF	<u>P TF</u>		

