USC...



PFT TF SKF

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	SKF	INTERCHANGE	
		FKL	USF
INTERCHANGE		FKL	LKF
FKL	LEP	FKL	UEN
FAG	<u>-</u>	FKL	LEN
NTN	<u>-</u>	FKL	UYN
коуо	<u>-</u>	FKL	LYN
INA	RRTY	FKL	USN
NSK	<u>ENPFL</u>	FKL	LKN
FKL	<u>UES</u>	FKL	UEG
FKL	<u>UYS</u>	FKL	LEG
FKL	<u>USS</u>	FKL	UYG
FKL	<u>LKS</u>	FKL	LYG
FKL	<u>UEV</u>	FKL	USG
FKL	<u>UYV</u>	FKL	LKG
FKL	<u>LYV</u>	FKL	UET
FKL	<u>USV</u>	FKL	LET
FKL	<u>LKV</u>	FKL	UYT
FKL	<u>UEU</u>	FKL	LYT
FKL	<u>LEU</u>	FKL	UST
FKL	<u>UYU</u>	FKL	LKT
FKL	<u>LYU</u>	FKL	UEC
FKL	<u>USU</u>	FKL	LEC
FKL	LKU	FKL	LYC
		1112	<u></u>

FKL





Bearings

INTERCHANGE		INTERCHANGE	
FKL	LKC	NTN	UKUP
FKL	UED	KOYO	UKPA
FKL	LED	SKF	SYF.RM
FKL	UYD	INA	PSHEY
FKL	LYD	SKF	SYF TF
FKL	USD	INA	RSHEY
FKL	LKD	SKF	SYF.FM
FKL	UEP	INA	PSHE
FKL	UYP	SKF	SYF.WF
FKL	LYP	INA	RSHE
FKL	USP	SKF	SYF.KF
FKL	LKP	коуо	
FKL	UER	FAG	FG762.B
FKL	LER	SKF	FYJ.KF
FKL	LYR	NSK	UKF
FKL	USR	NTN	UKF
FKL	LKR	KOYO	UKF
SKF	SYJ.RM	SKF	FYTJ.RM
INA	PASEY	INA	PCJTY
NSK	UBP	NSK	UBFL
NTN	ASP	NTN	ASFL
KOYO	SBP	KOYO	SBFL
SKF	SYJ.FM	SKF	FYTJ.TF
FAG	SG162	INA	RCJTY
INA	PASE	NSK	UCLF
NSK	ENP	NTN	UCFL
KOYO	SAP	KOYO	UCFL
SKF		SKF	FYTJ.FM
FAG	SG762.B	INA	PCJT
INA	-	NTN	AELFL
NSK		KOYO	SAFL
SKF	SYJ.KF	SKF	FYTJ.WF
NSK	UKP	INA	RCJT
NTN	UKP	NSK	EWFL
KOYO	UKP	NTN	UELFL
SKF	SYFJ.RM	коуо	NAFL
NSK	UBPA	SKF	FYTJ.KF
NTN	ASUP	NSK	UKFL
KOYO	SBPA	NTN	UKFL
SKF	SYFJ.FM	коуо	UKFL
NTN	AELUP	SKF	FYC.RM
KOYO	SAPA	NSK	UBFC
SKF	SYFJ.WF	NTN	ASFC
NSK	EWPA	коуо	SBFC
NTN	UELUP	SKF	FYC.TF
КОҮО	NAPA	NSK	UCFC
SKF	SYFJ.KF	NTN	UCFC
NSK	UKPA	KOYO	UCFC





Bearings

RRTRY PFD.FM RATR PFD.WF **RRTR** PFT.RM **RATY UBPFL ASPFL SBPFL** PFT.FM RAT AELPFL SAPFL PFT.WF RRT P.RM PBY UBPP **ASPP** SBPP P TF P.WF SB762.B LEV... UYF... SYFJ.TF **UCPA** <u>UCUP</u> **UCPA** FYJ.FM FG162 PCJ **AELF** SAF

INTERCHANGE		INTERCHANGE
SKF	FYC.FM_	INA
NTN	<u>AELFC</u>	SKF
SKF	FYC.WF	INA
INA	<u>RFE</u>	SKF
NSK	<u>EWFC</u>	INA
NTN	<u>UELFC</u>	SKF
KOYO	<u>NAFC</u>	INA
SKF	FYC.KF	NSK
NSK	<u>UKFC</u>	NTN
NTN	<u>UKFC</u>	KOYO
KOYO	<u>UKFC</u>	SKF
SKF	TU.RM_	INA
NSK	<u>UBT</u>	NTN
NTN	<u>AST</u>	KOYO
KOYO	<u>SBT</u>	SKF
SKF	TU.TF	INA
NSK	<u>UCT</u>	SKF
NTN	<u>UCT</u>	INA
KOYO	<u>UCT</u>	NSK
SKF	TU.FM_	NTN
INA	PTUE	KOYO
NSK	ENT	SKF
NTN	<u>AELT</u>	SKF
KOYO	SAT	FAG
SKF	TU.WF	FKL
INA	RTUE	FKL
NSK	<u>EWT</u>	SKF
NTN	<u>UELT</u>	NSK
KOYO	NAT	NTN
SKF	<u>TU.KF</u>	KOYO
NSK	<u>UKT</u>	SKF
NTN	<u>UKT</u>	FAG
KOYO	<u>UKT</u>	INA
SKF	PF.RM	NTN
INA	RAY	KOYO
NSK	<u>UBPF</u>	
NTN	<u>ASPF</u>	
KOYO	<u>SBPF</u>	
SKF	PF TF	
FAG	FB562_	
INA	RRY	
SKF	PF.WF	
FAG	FB362.B	
INA	RR	
FAG	FB762.B	
SKF	PFD.RM	
INA	<u>PATRY</u>	
SKF	PFD.TF	

