

LYP... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	<u>FKL</u>
INTERCHANGE	
FAG	<u>-</u>
NTN	<u>-</u>
NSK	<u>-</u>
KOYO	<u>-</u>
SKF	PFT.WF
INA	RRT
FKL	UES
FKL	UYS
FKL	<u>USS</u>
FKL	LKS
FKL	<u>UEV</u>
FKL	UYV
FKL	<u>LYV</u>
FKL	USV
FKL	<u>LKV</u>
FKL	<u>UEU</u>
FKL	<u>LEU</u>
FKL	<u>UYU</u>
FKL	LYU
FKL	<u>USU</u>
FKL	LKU

INTERCHANGE	
FKL	UYF
FKL	USF
FKL	LKF
FKL	UEN
FKL	LEN
FKL	UYN
FKL	LYN
FKL	USN
FKL	LKN
FKL	UEG
FKL	LEG
FKL	UYG
FKL	LYG
FKL	USG
FKL	LKG
FKL	<u>UET</u>
FKL	LET
FKL	UYT
FKL	LYT
FKL	UST
FKL	LKT
FKL	UEC
FKL	LEC
FKL	LYC





Bearings

INTERCHANGE		INTERCHANGE	
FKL	USC	NTN	UKUP
FKL	LKC	KOYO	UKPA
FKL	UED	SKF	SYF.RM
FKL	LED	INA	PSHEY
FKL	UYD	SKF	SYF TF
FKL	LYD	INA	RSHEY
FKL	USD	SKF	SYF.FM
FKL	LKD	INA	PSHE
FKL	UEP	SKF	SYF.WF
FKL	LEP	INA	RSHE
FKL	UYP	SKF	SYF.KF
FKL	USP	KOYO	
FKL	LKP	SKF	FYJ.FM
FKL	UER	FAG	FG162
FKL	LER	INA	PCJ
FKL	LYR	NTN	AELF
FKL	USR	KOYO	SAF
FKL	LKR	FAG	FG762.B
SKF	SYJ.RM	SKF	FYJ.KF
INA	PASEY	NSK	UKF
NSK	UBP	NTN	UKF
NTN	ASP	KOYO	UKF
KOYO	SBP	SKF	FYTJ.RM
SKF	SYJ.FM	INA	PCJTY
FAG	SG162	NSK	UBFL
INA	PASE	NTN	ASFL
NSK	ENP	KOYO	SBFL
KOYO	SAP	SKF	FYTJ.TF
SKF	-	INA	RCJTY
FAG	SG762.B	NSK	UCLF
INA		NTN	UCFL
SKF	SYJ.KF	KOYO	UCFL
NSK	UKP	SKF	FYTJ.FM
NTN	UKP	INA	PCJT
KOYO	UKP	NTN	AELFL
SKF	SYFJ.RM	KOYO	SAFL
NSK	UBPA	SKF	FYTJ.WF
NTN	ASUP	INA	RCJT
KOYO	SBPA	NSK	EWFL
SKF	SYFJ.FM	NTN	UELFL
NTN	AELUP	KOYO	NAFL
KOYO	SAPA	SKF	FYTJ.KF
SKF	SYFJ.WF	NSK	UKFL
NSK	EWPA	NTN	UKFL
NTN	UELUP	КОҮО	UKFL
KOYO	NAPA	SKF	FYC.RM
SKF	SYFJ.KF	NSK	UBFC
NSK	UKPA	NTN	ASFC
	<u>JKI A</u>		<u> </u>





Bearings

INTERCHANGE	INT	ERCHANGE
КОҮО	SBFC INA	RR
SKF	YC.TF FAG	<u>FB762.B</u>
NSK	<u>UCFC</u> SKF	PFD.RM
NTN	UCFC INA	PATRY
KOYO	<u>UCFC</u> SKF	PFD.TF
SKF <u>F</u>	YC.FM INA	RRTRY
NTN	AELFC SKF	PFD.FM
SKF F	C.WF INA	RATR
INA	RFE SKF	PFD.WF
NSK	EWFC INA	RRTR
NTN	JELFC SKF	PFT.RM
KOYO	NAFC INA	RATY
SKF	YC.KF NSK	<u>UBPFL</u>
NSK	<u>UKFC</u> NTN	ASPFL
NTN	<u>UKFC</u> KOY	O SBPFL
KOYO	<u>UKFC</u> SKF	PFT TF
SKF	TU.RM INA	RRTY
NSK	<u>UBT</u> NSk	<u>ENPFL</u>
NTN	AST SKF	PFT.FM_
KOYO	SBT INA	RAT
SKF	TU.TF NTN	<u>AELPFL</u>
NSK	UCT KOY	O SAPFL
NTN	<u>UCT</u> SKF	P.RM_
KOYO	UCT INA	PBY
SKF	TU.FM NSK	<u>UBPP</u>
INA	PTUE NTN	ASPP
NSK	ENT KOY	O SBPP
NTN	AELT SKF	<u>P TF</u>
KOYO	SAT SKF	P.WF
SKF	U.WF FAG	<u>SB762.B</u>
INA	RTUE FKL	LEV
NSK	EWT SKF	SYFJ.TF_
NTN	<u>UELT</u> NSk	<u>UCPA</u>
KOYO	NTN NTN	<u>UCUP</u>
SKF	TU.KF KOY	O <u>UCPA</u>
NSK	<u>UKT</u>	
NTN	<u>UKT</u>	
KOYO	<u>UKT</u>	
SKF	PF.RM_	
INA	RAY	
NSK	<u>UBPF</u>	
NTN	ASPF	
KOYO	SBPF	
SKF	PF TF	
FAG	B562	
INA	RRY	
	PF.WF	
FAG FB	362.B	

