

## VS116 NTN

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, TORRINGTON-KOYO



### Technical specification

**MANUFACTURER** [NTN](#)

**INTERCHANGE**

|            |                       |
|------------|-----------------------|
| TORRINGTON | <a href="#">B-116</a> |
| INA        | <a href="#">S116</a>  |