

## **SH108 INA**

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, TORRINGTON-KOYO



## **Technical specification**

| MANUFACTURER | INA           |
|--------------|---------------|
| INTERCHANGE  |               |
| TORRINGTON   | BH-108        |
| IKO          | <u>YBH108</u> |
| NTN          | <u>VSH108</u> |
| SKF          | BH108         |