



## FH201-8 PEER

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units (part 3)



## **Technical specification**

MANUFACTURER	PEER
INTERCHANGE	
ABC	<u>SA201-8</u>
ASAHI	<u>KH201-8</u>
AMI	<u>KH201-8</u>
NTN	AEL201-008
NSK	EN201-85
FYH	<u>SA201-8</u>
КОҮО	<u>SA201-8</u>
IPTCI	<u>SA201-8</u>
SNR	ES201-8
NEUTRAL	<u>UE201-8</u>
FAFNIR	GRA008RRB
SEALMASTER	<u>V-08E</u>
INA	GRA008NPPB
DODGE	INS-SXV-008
BROWNING	<u>VE-108</u>
HUB-CITY	B220x1/2

