

ES201-8 SNR

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units (part 3)



Technical specification

MANUFACTURER

[SNR](#)

INTERCHANGE

ABC	SA201-8
ASAHI	KH201-8
AMI	KH201-8
NTN	AEL201-008
NSK	EN201-8S
FYH	SA201-8
KOYO	SA201-8
IPTCI	SA201-8
PEER	FH201-8
NEUTRAL	UE201-8
FAFNIR	GRA008RRB
SEALMASTER	V-08E
INA	GRA008NPPB
DODGE	INS-SXV-008
BROWNING	VE-108
HUB-CITY	B220x1/2