

## INS-SXV-008 DODGE

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units (part 3)



### Technical specification

**MANUFACTURER** [DODGE](#)

#### INTERCHANGE

ABC	<a href="#">SA201-8</a>
ASAHI	<a href="#">KH201-8</a>
AMI	<a href="#">KH201-8</a>
NTN	<a href="#">AEL201-008</a>
NSK	<a href="#">EN201-8S</a>
FYH	<a href="#">SA201-8</a>
KOYO	<a href="#">SA201-8</a>
IPTCI	<a href="#">SA201-8</a>
PEER	<a href="#">FH201-8</a>
SNR	<a href="#">ES201-8</a>
NEUTRAL	<a href="#">UE201-8</a>
FAFNIR	<a href="#">GRA008RRB</a>
SEALMASTER	<a href="#">V-08E</a>
INA	<a href="#">GRA008NPPB</a>
BROWNING	<a href="#">VE-108</a>
HUB-CITY	<a href="#">B220x1/2</a>