

## **INS-SXV-008 DODGE**

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units (part 3)



## **Technical specification**

MANUFACTURER	DODGE
INTERCHANGE	
ABC	SA201-8
ASAHI	KH201-8
AMI	<u>KH201-8</u>
NTN	AEL201-008
NSK	EN201-8S
FYH	SA201-8
KOYO	SA201-8
IPTCI	SA201-8
PEER	FH201-8
SNR	ES201-8
NEUTRAL	<u>UE201-8</u>
FAFNIR	GRA008RRB
SEALMASTER	<u>V-08E</u>
INA	GRA008NPPB
BROWNING	<u>VE-108</u>
HUB-CITY	B220x1/2

