

## H20EA/ H20EB TSUBAKI

Interchange tables

TYPE: Cross reference, interchange tables, HIWIN linear guide systems



### Technical specification

**MANUFACTURER** [TSUBAKI](#)

#### INTERCHANGE

|               |   |
|---------------|---|
| ABC           | <a href="#">HGW20CB</a>                                       |
| HIWIN         | <a href="#">HGW20CB/ LGW20CB/ HGW20CC</a>                     |
| THK           | <a href="#">HSR20B/ HSR20CB/ SHS20C</a>                       |
| NSK           | <a href="#">LAH20FL/ LY20FL/ LH20FL</a>                       |
| BOSCH REXROTH | <a href="#">1651-8..-10*</a>                                  |
| IKO           | <a href="#">LWH20..B</a>                                      |
| INA           | <a href="#">KWE20- KUE20/ KWVE20- KUVE20/ KWSE20- KUSE20*</a> |
| THOMSON       | <a href="#">AG20AA/ AT20A*</a>                                |
| NB            | <a href="#">SGL20HTE</a>                                      |
| SCHNEEBERGER  | <a href="#">BMA20*</a>  |
| PMI           | <a href="#">MSA20E</a>  |
| NITEK         | <a href="#">NFL20CC*</a>                                      |
| SKF           | <a href="#">LLBHS20B</a>                                      |
| ABBA          | <a href="#">BRH20A/ BRH20C</a>                                |
| SBC           | <a href="#">SBG20FL</a>                                       |