

UET... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	FKL	INTERCHAI
INTERCHANCE		FKL
INTERCHANGE		FKL
FAG	<u> </u>	FKL
INA	<u>-</u>	FKL
SKF	<u>TU.RM</u>	FKL
NSK	<u>UBT</u>	FKL
NTN	<u>AST</u>	FKL
KOYO	<u>SBT</u>	FKL
FKL	<u>UES</u>	FKL
FKL	<u>USS</u>	FKL
FKL	<u>LKS</u>	FKL
FKL	<u>UEV</u>	FKL
FKL	<u>LEV</u>	FKL
FKL	<u>UYV</u>	FKL
FKL	<u>LYV</u>	FKL
FKL	USV	FKL
FKL	LKV	FKL
FKL	<u>UEU</u>	FKL
FKL	<u>LEU</u>	FKL
FKL	UYU	FKL
FKL	LYU	FKL
FKL	USU	FKL
FKL	LKU	FKL
		ΓNL

INTERCHANGE	
FKL	<u>USF</u>
FKL	LKF
FKL	UEN
FKL	LEN
FKL	UYN
FKL	LYN
FKL	USN
FKL	LKN
FKL	UEG
FKL	LEG
FKL	UYG
FKL	LYG
FKL	<u>USG</u>
FKL	LKG
FKL	<u>LET</u>
FKL	<u>UYT</u>
FKL	<u>LYT</u>
FKL	<u>UST</u>
FKL	<u>LKT</u>
FKL	<u>UEC</u>
FKL	<u>USC</u>
FKL	<u>LKC</u>
FKL	<u>UED</u>
FKL	LED





Bearings

INTERCHANGE		INTERCHANGE	
FKL	UYD	SKF	SYF.RM
FKL	LYD	INA	PSHEY
FKL	USD	SKF	SYF TF
FKL	LKD	INA	RSHEY
FKL	UEP	SKF	SYF.FM
FKL	LEP	INA	PSHE
FKL	UYP	SKF	SYF.WF
FKL	LYP	INA	RSHE
FKL	USP	SKF	SYF.KF
FKL	LKP	KOYO	
FKL	UER	FAG	FG762.B
FKL	LER	SKF	FYJ.KF
FKL	LYR	NSK	UKF
FKL	USR	NTN	UKF
FKL	LKR	KOYO	UKF
SKF	SYJ.RM	SKF	FYTJ.RM
INA	PASEY	INA	PCJTY
NSK	UBP	NSK	UBFL
NTN	ASP	NTN	ASFL
KOYO	SBP	KOYO	SBFL
NTN	-	SKF	FYTJ.TF
SKF	-	INA	RCJTY
FAG	SG762.B	NSK	UCLF
NSK		NTN	UCFL
KOYO	-	KOYO	UCFL
SKF	SYJ.KF	SKF	FYTJ.FM
NSK	UKP	INA	PCJT
NTN	UKP	NTN	AELFL
KOYO	UKP	KOYO	SAFL
SKF	SYFJ.RM	SKF	FYTJ.WF
NSK	UBPA	INA	RCJT
NTN	ASUP	NSK	EWFL
KOYO	SBPA	NTN	UELFL
SKF	SYFJ.TF	коуо	NAFL
NSK	<u>UCPA</u>	SKF	FYTJ.KF
NTN	UCUP	NSK	UKFL
KOYO	UCPA	NTN	UKFL
SKF	SYFJ.FM	KOYO	UKFL
NTN	<u>AELUP</u>	SKF	FYC.RM
KOYO	SAPA	NSK	UBFC
SKF	SYFJ.WF	NTN	ASFC
NSK	EWPA	коуо	SBFC
NTN	<u>UELUP</u>	SKF	FYC.TF
КОҮО	NAPA	NSK	<u>UCFC</u>
SKF	SYFJ.KF	NTN	UCFC
NSK	UKPA	коуо	<u>UCFC</u>
NTN	<u>UKUP</u>	SKF	FYC.FM
KOYO	UKPA	NTN	AELFC





Bearings

INTERCHANGE		INTERCHANGE	
SKF	FYC.WF	NSK	<u>ENPFL</u>
INA	<u>RFE</u>	SKF	PFT.FM
NSK	<u>EWFC</u>	INA	RAT
NTN	<u>UELFC</u>	NTN	<u>AELPFL</u>
KOYO	<u>NAFC</u>	KOYO	<u>SAPFL</u>
SKF	FYC.KF	SKF	PFT.WF
NSK	<u>UKFC</u>	INA	RRT
NTN	<u>UKFC</u>	SKF	P.RM
KOYO	<u>UKFC</u>	INA	<u>PBY</u>
SKF	TU.TF_	NSK	<u>UBPP</u>
NSK	<u>UCT</u>	NTN	ASPP
NTN	<u>UCT</u>	KOYO	SBPP
KOYO	<u>UCT</u>	SKF	<u>P TF</u>
SKF	TU.FM_	SKF	P.WF
INA	<u>PTUE</u>	FAG	SB762.B
NSK	ENT	FKL	UYS
NTN	<u>AELT</u>	FKL	UYF
KOYO	SAT	FKL	<u>LEC</u>
SKF	TU.WF	FKL	LYC
INA	RTUE	SKF	SYJ.FM
NSK	EWT	FAG	<u>SG162</u>
NTN	UELT	INA	PASE
KOYO	NAT	NSK	<u>ENP</u>
SKF	<u>TU.KF</u>	KOYO	SAP
NSK	<u>UKT</u>	SKF	<u>FYJ.FM</u>
NTN	<u>UKT</u>	FAG	FG162
KOYO	<u>UKT</u>	INA	<u>PCJ</u>
SKF	PF.RM_	NTN	<u>AELF</u>
INA	RAY	KOYO	SAF
NSK	<u>UBPF</u>	SKF	PF TF
NTN	<u>ASPF</u>	FAG	FB562
КОУО	SBPF	INA	RRY
FAG	FB762.B	SKF	PF.WF
SKF	PFD.RM	FAG	FB362.B
INA	<u>PATRY</u>	INA	RR
SKF	PFD.TF		
INA	RRTRY		
SKF	PFD.FM		
INA	RATR		
SKF	PFD.WF		
INA	RRTR		
SKF	PFT.RM		
INA NSK	RATY UBPFL		
NTN	ASPFL		
KOYO			
	SBPFL DET TE		
SKF INA	PFT TF		
IIVA	RRTY		

