

RR INA

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	INA	INTERCHANGE	
		FKL	<u>USG</u>
		FKL	<u>UST</u>
FKL	<u>LYC</u>	FKL	<u>LEC</u>
NTN	<u> </u>	FKL	<u>USC</u>
NSK	<u>-</u>	FKL	<u>LKC</u>
КОҮО	-	FKL	UED
SKF	PF.WF	FKL	LED
FAG	FB362.B	FKL	UYD
FKL	<u>UYS</u>	FKL	LYD
FKL	<u>USS</u>	FKL	USD
FKL	<u>UYV</u>	FKL	LKD
FKL	<u>USV</u>	FKL	LEP
FKL	<u>UEU</u>	FKL	UYP
FKL	<u>LEU</u>	FKL	LYP
FKL	<u>UYU</u>	FKL	USP
FKL	<u>LYU</u>	FKL	LKP
FKL	<u>USU</u>	FKL	LER
FKL	<u>LKU</u>	FKL	LYR
FKL	<u>UYF</u>	FKL	USR
FKL	<u>USF</u>	FKL	<u>LKR</u>
FKL	<u>UYN</u>	SKF	SYJ.FM
FKL	<u>USN</u>	FAG	SG162
FKL	<u>UYG</u>	INA	PASE
		NSK	ENP





Bearings

INTERCHANGE		INTERCHANGE	
КОҮО	<u>SAP</u>	КОҮО	SAPFL
SKF	-	SKF	PFT.WF
FAG	<u>SG762.B</u>	INA	RRT
INA	-	SKF	<u>P TF</u>
FAG	-	SKF	P.WF
SKF	SYFJ.FM	FAG	<u>SB762.B</u>
NTN	AELUP	FKL	<u>UES</u>
КОҮО	<u>SAPA</u>	FKL	<u>LKS</u>
SKF	SYF.RM	FKL	<u>UEV</u>
INA	PSHEY	FKL	LEV
SKF	SYF TF	FKL	<u>LYV</u>
INA	RSHEY	FKL	LKV
SKF	SYF.FM	FKL	<u>LKF</u>
INA	PSHE	FKL	<u>UEN</u>
SKF	SYF.WF	FKL	LEN
INA	RSHE	FKL	LYN
SKF	SYF.KF	FKL	LKN
КОҮО		FKL	UEG
SKF	FYJ.FM	FKL	LEG
FAG	FG162	FKL	LYG
INA	PCJ	FKL	LKG
NTN	AELF	FKL	UET
КОҮО	SAF	FKL	LET
FAG	FG762.B	FKL	UYT
SKF	FYTJ.FM	FKL	<u>LYT</u>
INA	PCJT	FKL	LKT
NTN	AELFL	FKL	UEC
КОҮО	SAFL	FKL	UEP
SKF	FYC.FM	FKL	UER
NTN	AELFC	SKF	SYJ.RM
SKF	PF TF	INA	PASEY
FAG	FB562	NSK	UBP
INA	RRY	NTN	ASP
FAG	FB762.B	КОҮО	SBP
SKF	PFD.RM	SKF	SYJ.KF
INA	PATRY	NSK	UKP
SKF	PFD.TF	NTN	UKP
INA	RRTRY	КОҮО	UKP
SKF	PFD.FM	SKF	SYFJ.RM
INA	RATR	NSK	UBPA
SKF	PFD.WF	NTN	ASUP
INA	RRTR	КОҮО	SBPA
SKF	PFT TF	SKF	SYFJ.TF
INA	RRTY	NSK	UCPA
NSK	ENPFL	NTN	UCUP
SKF	PFT.FM	КОҮО	UCPA
INA	RAT	SKF	SYFJ.WF
NTN	AELPFL	NSK	EWPA
		HUN	





Bearings

INTERCHANGE		INTERCHANGE	
NTN	UELUP	NTN	AST
КОҮО	NAPA	КОҮО	<u>SBT</u>
SKF	<u>SYFJ.KF</u>	SKF	<u>TU.TF</u>
NSK	UKPA	NSK	UCT
NTN	<u>UKUP</u>	NTN	UCT
КОҮО	UKPA	КОҮО	UCT
SKF	FYJ.KF	SKF	TU.FM
NSK	UKF	INA	PTUE
NTN	<u>UKF</u>	NSK	ENT
КОҮО	UKF	NTN	AELT
SKF	FYTJ.RM	КОҮО	SAT
INA	PCJTY	SKF	TU.WF
NSK	UBFL	INA	RTUE
NTN	ASFL	NSK	<u>EWT</u>
КОҮО	<u>SBFL</u>	NTN	<u>UELT</u>
SKF	FYTJ.TF	КОҮО	NAT
INA	<u>RCJTY</u>	SKF	<u>TU.KF</u>
NSK	UCLF	NSK	UKT
NTN	UCFL	NTN	<u>UKT</u>
КОҮО	UCFL	КОҮО	UKT
SKF	FYTJ.WF	SKF	PF.RM
INA	RCJT	INA	RAY
NSK	EWFL	NSK	UBPF
NTN	UELFL	NTN	ASPF
КОҮО	NAFL	КОҮО	<u>SBPF</u>
SKF	FYTJ.KF	SKF	PFT.RM
NSK	UKFL	INA	RATY
NTN	UKFL	NSK	UBPFL
КОҮО	<u>UKFL</u>	NTN	ASPFL
SKF	FYC.RM	КОҮО	<u>SBPFL</u>
NSK	<u>UBFC</u>	SKF	P.RM
NTN	ASFC	INA	PBY
КОҮО	<u>SBFC</u>	NSK	<u>UBPP</u>
SKF	FYC.TF	NTN	ASPP
NSK	UCFC	КОҮО	<u>SBPP</u>
NTN	UCFC		
КОҮО	UCFC		
SKF	FYC.WF		
INA	<u>RFE</u>		
NSK	EWFC		
NTN	UELFC		
КОҮО	NAFC		
SKF	FYC.KF		
NSK	UKFC		
NTN	<u>UKFC</u>		
КОҮО	UKFC		
SKF	TU.RM		
NSK	UBT		

