

PFD.RM SKF

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



INTERCUANCE

Technical specification

MANUFACTURER	<u>SKF</u>	INTERCHANGE	
		FKL	UYF
INTERCHANGE		FKL	USF
FKL	UED	FKL	LKF
FAG	<u>-</u>	FKL	UEN
NTN	<u>_</u>	FKL	LEN
NSK	<u>-</u>	FKL	UYN
KOYO		FKL	LYN
INA	<u>PATRY</u>	FKL	USN
FKL	<u>UES</u>	FKL	LKN
FKL	<u>UYS</u>	FKL	UEG
FKL	<u>USS</u>	FKL	LEG
FKL	<u>LKS</u>	FKL	UYG
FKL	<u>UEV</u>	FKL	LYG
FKL	<u>UYV</u>	FKL	USG
FKL	LYV	FKL	LKG
FKL	<u>USV</u>	FKL	UET
FKL	<u>LKV</u>	FKL	LET
FKL	<u>UEU</u>	FKL	UYT
FKL	<u>LEU</u>	FKL	LYT
FKL	<u>UYU</u>	FKL	UST
FKL	LYU	FKL	LKT
FKL	USU	FKL	UEC
FKL	<u>LKU</u>	FKL	LEC
		FKL	LYC





Bearings

INTERCHANGE	II	NTERCHANGE	
FKL	JSC	NTN	UKUP
FKL	KC K	KOYO	UKPA
FKL	ED S	SKF	SYF.RM
FKL	JYD II	NA	PSHEY
FKL	<u>YD</u> S	SKF	SYF TF
FKL	JSD II	NA	RSHEY
FKL	KD S	SKF	SYF.FM_
FKL	JEP II	NA	PSHE
FKL	LEP S	SKF	SYF.WF
FKL	JYP II	NA	RSHE
FKL	LYP	SKF	SYF.KF
FKL	JSP K	KOYO	<u></u>
FKL	LKP	SKF	FYJ.FM_
FKL	JER F	FAG	FG162
FKL	_ER II	NA	PCJ
FKL	_YR N	NTN	AELF
FKL	JSR K	KOYO	SAF
FKL	_KR F	FAG	FG762.B
SKF S	YJ.RM S	SKF	FYJ.KF
INA	ASEY N	NSK	UKF
NSK	<u>UBP</u> N	NTN	UKF
NTN	ASP K	KOYO	UKF
KOYO	SBP S	SKF	FYTJ.RM
SKF S	YJ.FM II	NA	PCJTY
FAG S	G162 N	NSK	<u>UBFL</u>
INA	PASE N	NTN	ASFL
NSK	<u>ENP</u> K	KOYO	SBFL
KOYO	SAP S	SKF	FYTJ.TF
SKF	<u>-</u> II	NA	<u>RCJTY</u>
FAG SGT	762.B	NSK	<u>UCLF</u>
INA	<u>-</u> N	NTN	<u>UCFL</u>
SKF	SYJ.KF K	KOYO	<u>UCFL</u>
NSK	<u>UKP</u> S	SKF	FYTJ.FM_
NTN	<u>UKP</u> II	NA	PCJT
KOYO	<u>UKP</u> N	NTN	<u>AELFL</u>
SKF <u>SY</u>	FJ.RM_ K	KOYO	SAFL
NSK	UBPA S	SKF	FYTJ.WF
NTN	ASUP_ II	NA	RCJT
KOYO	SBPA N	NSK	<u>EWFL</u>
SKF <u>SY</u>	FJ.FM_N	NTN	<u>UELFL</u>
NTN	<u>ELUP</u> K	KOYO	<u>NAFL</u>
KOYO	SAPA S	SKF	FYTJ.KF
SKF <u>SY</u>	FJ.WF_	NSK	<u>UKFL</u>
NSK	WPA N	NTN	UKFL
NTN <u>U</u>	<u>ELUP</u> K	KOYO	<u>UKFL</u>
KOYO	NAPA S	SKF	FYC.RM
SKF SY	<u>FJ.KF</u>	NSK	<u>UBFC</u>
NSK	UKPA N	NTN	<u>ASFC</u>





Bearings

INTERCHANGE		INTERCHANGE	
KOYO	SBFC	INA	RR
SKF	FYC.TF	FAG	FB762.B
NSK	<u>UCFC</u>	SKF	PFD.TF
NTN	<u>UCFC</u>	INA	RRTRY
KOYO	<u>UCFC</u>	SKF	PFD.FM
SKF	FYC.FM	INA	RATR
NTN	<u>AELFC</u>	SKF	PFD.WF
SKF	FYC.WF	INA	<u>RRTR</u>
INA	RFE	SKF	PFT.RM
NSK	<u>EWFC</u>	INA	RATY
NTN	<u>UELFC</u>	NSK	<u>UBPFL</u>
KOYO	<u>NAFC</u>	NTN	ASPFL
SKF	FYC.KF	KOYO	SBPFL
NSK	<u>UKFC</u>	SKF	PFT TF
NTN	<u>UKFC</u>	INA	RRTY
KOYO	<u>UKFC</u>	NSK	ENPFL
SKF	<u>TU.RM</u>	SKF	PFT.FM
NSK	<u>UBT</u>	INA	RAT
NTN	<u>AST</u>	NTN	<u>AELPFL</u>
KOYO	<u>SBT</u>	KOYO	SAPFL
SKF	TU.TF	SKF	PFT.WF
NSK	<u>UCT</u>	INA	RRT
NTN	<u>UCT</u>	SKF	P.RM
KOYO	<u>UCT</u>	INA	<u>PBY</u>
SKF	TU.FM_	NSK	<u>UBPP</u>
INA	PTUE	NTN	<u>ASPP</u>
NSK	<u>ENT</u>	KOYO	<u>SBPP</u>
NTN	<u>AELT</u>	SKF	<u>P TF</u>
KOYO	SAT	SKF	P.WF
SKF	TU.WF	FAG	<u>SB762.B</u>
INA	RTUE	FKL	LEV
NSK	EWT	SKF	SYFJ.TF
NTN	<u>UELT</u>	NSK	<u>UCPA</u>
KOYO	NAT	NTN	<u>UCUP</u>
SKF	<u>TU.KF</u>	KOYO	<u>UCPA</u>
NSK	<u>UKT</u>		
NTN	<u>UKT</u>		
КОУО	<u>UKT</u>		
SKF	PF.RM_		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	ASPF		
KOYO	SBPF_		
SKF	PF TF		
FAG	FB562		
INA	RRY		
SKF	PF.WF		
FAG	FB362.B		

