

## **PATRY INA**

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



INTERCUANCE

## **Technical specification**

MANUFACTURER	<u>INA</u> <b>IN</b> 7	TERCHANGE
INTERCHANGE	FK	L
	FK	L
FKL	UED FK	L
FAG	- FK	L
NTN	<u>-</u> FK	L
NSK	<u>-</u> FK	L
KOYO	<u>-</u> FK	
SKF	PFD.RM FK	
FKL	UES FK	
FKL	UYS FK	
FKL	USS FK	
FKL	LKS FK	
FKL	UEV FK	
FKL	UYV FK	
FKL	LVV	
FKL	IIC\/	
FKL	I K//	
FKL	LIEU	
FKL	LEIL	
FKL	LIVII	
FKL	IVII	
FKL	IICII	
FKL	IVII	
INL	FK	L

INTERCHANGE	
FKL	<u>UYF</u>
FKL	<u>USF</u>
FKL	<u>LKF</u>
FKL	<u>UEN</u>
FKL	<u>LEN</u>
FKL	UYN
FKL	<u>LYN</u>
FKL	USN
FKL	<u>LKN</u>
FKL	UEG
FKL	<u>LEG</u>
FKL	UYG
FKL	LYG
FKL	USG
FKL	LKG
FKL	<u>UET</u>
FKL	<u>LET</u>
FKL	<u>UYT</u>
FKL	<u>LYT</u>
FKL	UST
FKL	<u>LKT</u>
FKL	<u>UEC</u>
FKL	<u>LEC</u>
FKL	LYC





## **Bearings**

INTERCHANGE INTER	CHANGE
FKL USC NTN	UKUP
FKL LKC KOYO	UKPA
FKL LED SKF	SYF.RM
FKL UYD INA	PSHEY
FKL LYD SKF	SYF TF
FKL USD INA	RSHEY
FKL LKD SKF	SYF.FM_
FKL UEP INA	PSHE
FKL LEP SKF	SYF.WF
FKL <u>UYP</u> INA	RSHE
FKL LYP SKF	SYF.KF_
FKL USP KOYO	<u></u>
FKL LKP SKF	<u>FYJ.FM</u>
FKL <u>UER</u> FAG	FG162
FKL LER INA	PCJ
FKL LYR NTN	AELF
FKL USR KOYO	SAF
FKL LKR FAG	FG762.B
SKF SYJ.RM SKF	FYJ.KF
INA PASEY NSK	UKF
NSK UBP NTN	UKF
NTN ASP KOYO	UKF
KOYO SBP SKF	FYTJ.RM
SKF SYJ.FM INA	PCJTY
FAG SG162 NSK	UBFL
INA PASE NTN	ASFL
NSK ENP KOYO	SBFL
KOYO SAP SKF	FYTJ.TF
SKF - INA	RCJTY
FAG <u>SG762.B</u> NSK	UCLF
INA _ NTN	<u>UCFL</u>
SKF <u>SYJ.KF</u> KOYO	UCFL
NSK UKP SKF	FYTJ.FM_
NTN <u>UKP</u> INA	<u>PCJT</u>
KOYO <u>UKP</u> NTN	<u>AELFL</u>
SKF <u>SYFJ.RM</u> KOYO	SAFL
NSK <u>UBPA</u> SKF	<u>FYTJ.WF</u>
NTN <u>ASUP</u> INA	<u>RCJT</u>
KOYO <u>SBPA</u> NSK	<u>EWFL</u>
SKF <u>SYFJ.FM</u> NTN	<u>UELFL</u>
NTN <u>AELUP</u> KOYO	NAFL_
KOYO SAPA SKF	FYTJ.KF
SKF <u>SYFJ.WF</u> NSK	UKFL
NSK <u>EWPA</u> NTN	UKFL
NTN <u>UELUP</u> KOYO	UKFL
KOYO NAPA SKF	FYC.RM
SKF SYFJ.KF NSK	UBFC
NSK <u>UKPA</u> NTN	ASFC





## **Bearings**

INTERCHANGE		INTERCHANGE	
KOYO	SBFC	INA	RR
SKF	FYC.TF	FAG	FB762.B
NSK	<u>UCFC</u>	SKF	PFD.TF
NTN	<u>UCFC</u>	INA	RRTRY
KOYO	<u>UCFC</u>	SKF	PFD.FM
SKF	FYC.FM	INA	RATR
NTN	<u>AELFC</u>	SKF	PFD.WF
SKF	FYC.WF	INA	<u>RRTR</u>
INA	RFE	SKF	PFT.RM
NSK	<u>EWFC</u>	INA	RATY
NTN	<u>UELFC</u>	NSK	<u>UBPFL</u>
KOYO	<u>NAFC</u>	NTN	ASPFL
SKF	FYC.KF	KOYO	SBPFL
NSK	<u>UKFC</u>	SKF	PFT TF
NTN	<u>UKFC</u>	INA	RRTY
KOYO	<u>UKFC</u>	NSK	ENPFL
SKF	<u>TU.RM</u>	SKF	PFT.FM
NSK	<u>UBT</u>	INA	RAT
NTN	<u>AST</u>	NTN	<u>AELPFL</u>
KOYO	<u>SBT</u>	KOYO	SAPFL
SKF	TU.TF	SKF	PFT.WF
NSK	<u>UCT</u>	INA	RRT
NTN	<u>UCT</u>	SKF	P.RM
KOYO	<u>UCT</u>	INA	<u>PBY</u>
SKF	TU.FM_	NSK	<u>UBPP</u>
INA	PTUE	NTN	<u>ASPP</u>
NSK	<u>ENT</u>	KOYO	<u>SBPP</u>
NTN	<u>AELT</u>	SKF	<u>P TF</u>
KOYO	SAT	SKF	P.WF
SKF	TU.WF	FAG	<u>SB762.B</u>
INA	RTUE	FKL	<u>LEV</u>
NSK	EWT	SKF	SYFJ.TF
NTN	<u>UELT</u>	NSK	<u>UCPA</u>
KOYO	NAT	NTN	<u>UCUP</u>
SKF	<u>TU.KF</u>	KOYO	<u>UCPA</u>
NSK	<u>UKT</u>		
NTN	<u>UKT</u>		
КОУО	<u>UKT</u>		
SKF	PF.RM_		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	ASPF		
KOYO	SBPF_		
SKF	PF TF		
FAG	FB562		
INA	RRY		
SKF	PF.WF		
FAG	FB362.B		

