

PFD.WF SKF

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	SKF	INTERCHANGE	
INTERCUANCE		FKL	<u>UYF</u>
INTERCHANGE	LVD	FKL	<u>USF</u>
FKL	LYD	FKL	<u>LKF</u>
FAG	<u>-</u>	FKL	UEN
NTN	<u>-</u>	FKL	LEN
NSK	<u> </u>	FKL	UYN
KOYO		FKL	LYN
INA	RRTR	FKL	USN
FKL	UES	FKL	LKN
FKL	UYS	FKL	UEG
FKL	USS	FKL	LEG
FKL	LKS	FKL	UYG
FKL	UEV	FKL	LYG
FKL	UYV	FKL	USG
FKL	LYV	FKL	<u>LKG</u>
FKL	USV	FKL	<u>UET</u>
FKL	<u>LKV</u>	FKL	<u>LET</u>
FKL	UEU	FKL	<u>UYT</u>
FKL	LEU	FKL	<u>LYT</u>
FKL	<u>UYU</u>	FKL	UST
FKL	LYU	FKL	LKT
FKL	USU	FKL	UEC
FKL	<u>LKU</u>	FKL	LEC
		FKL	LYC





Bearings

INTERCHANGE	INTERCHANGE	
FKL	SC NTN	UKUP
FKL	KC KOYO	UKPA
FKL	ED SKF	SYF.RM
	ED INA	PSHEY
FKL	YD SKF	SYF TF
_	SD INA	RSHEY
	KD SKF	SYF.FM
FKL	EP INA	PSHE
FKL	EP SKF	SYF.WF_
FKL	YP INA	RSHE
FKL	YP SKF	SYF.KF_
FKL	SP KOYO	<u></u>
FKL	KP SKF	FYJ.FM_
FKL	ER FAG	FG162
FKL	ER INA	PCJ
FKL	YR NTN	AELF
FKL	SR KOYO	SAF
FKL	KR FAG	FG762.B
SKF SY	J.RM SKF	FYJ.KF
INA PA	ASEY NSK	UKF
NSK	UBPNTN	UKF
NTN	ASP KOYO	UKF
KOYO	SBP SKF	FYTJ.RM
SKF S	J.FM INA	PCJTY
FAG S0	NSK	UBFL
INA	PASE NTN	ASFL
NSK	ENP KOYO	SBFL
КОҮО	SAP SKF	FYTJ.TF_
SKF	_ INA	RCJTY
FAG SG7	62.B NSK	UCLF
INA	_ NTN	<u>UCFL</u>
SKF S	YJ.KF KOYO	UCFL
NSK	<u>UKP</u> SKF	FYTJ.FM_
NTN	UKP INA	PCJT
КОУО	<u>UKP</u> NTN	AELFL
SKF SYF	J.RM KOYO	SAFL
NSK	JBPA SKF	FYTJ.WF_
NTN	ASUP INA	RCJT
KOYO	SBPA NSK	<u>EWFL</u>
SKF <u>SY</u>	J.FMNTN	<u>UELFL</u>
NTN	<u>LUP</u> KOYO	NAFL_
KOYO	SAPA SKF	FYTJ.KF
SKF SYF	J.WF_ NSK	<u>UKFL</u>
NSK	WPA NTN	UKFL
NTN	LUP KOYO	UKFL
KOYO	IAPA SKF	FYC.RM
SKF SY	FJ.KF_ NSK	<u>UBFC</u>
NSK	JKPA NTN	ASFC





Bearings

INTERCHANGE		INTERCHANGE	
KOYO	SBFC	INA	RR
SKF	FYC.TF	FAG	FB762.B
NSK	<u>UCFC</u>	SKF	PFD.RM
NTN	<u>UCFC</u>	INA	<u>PATRY</u>
KOYO	<u>UCFC</u>	SKF	PFD.TF
SKF	FYC.FM	INA	RRTRY
NTN	<u>AELFC</u>	SKF	PFD.FM
SKF	FYC.WF	INA	RATR
INA	<u>RFE</u>	SKF	PFT.RM
NSK	<u>EWFC</u>	INA	RATY
NTN	<u>UELFC</u>	NSK	<u>UBPFL</u>
KOYO	NAFC	NTN	<u>ASPFL</u>
SKF	FYC.KF	KOYO	<u>SBPFL</u>
NSK	<u>UKFC</u>	SKF	PFT TF
NTN	<u>UKFC</u>	INA	<u>RRTY</u>
KOYO	<u>UKFC</u>	NSK	ENPFL
SKF	TU.RM_	SKF	PFT.FM
NSK	<u>UBT</u>	INA	RAT
NTN	<u>AST</u>	NTN	<u>AELPFL</u>
KOYO	SBT	KOYO	SAPFL
SKF	<u>TU.TF</u>	SKF	PFT.WF
NSK	<u>UCT</u>	INA	RRT
NTN	<u>UCT</u>	SKF	P.RM
KOYO	<u>UCT</u>	INA	<u>PBY</u>
SKF	<u>TU.FM</u>	NSK	<u>UBPP</u>
INA	PTUE	NTN	<u>ASPP</u>
NSK	<u>ENT</u>	KOYO	<u>SBPP</u>
NTN	AELT	SKF	<u>P TF</u>
KOYO	SAT	SKF	P.WF
SKF	TU.WF	FAG	<u>SB762.B</u>
INA	RTUE	FKL	LEV
NSK	EWT	SKF	SYFJ.TF
NTN	<u>UELT</u>	NSK	<u>UCPA</u>
KOYO	NAT	NTN	<u>UCUP</u>
SKF	<u>TU.KF</u>	KOYO	<u>UCPA</u>
NSK	<u>UKT</u>		
NTN	<u>UKT</u>		
КОУО	<u>UKT</u>		
SKF	PF.RM		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	<u>ASPF</u>		
KOYO	<u>SBPF</u>		
SKF	PF TF		
FAG	FB562		
INA	RRY		
SKF	PF.WF		
FAG	FB362.B		

