

LKD... FKL

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	<u>FKL</u>
INTERCHANGE	
FAG	<u>-</u>
NTN	<u>-</u>
SKF	<u> </u>
INA	<u>-</u>
NSK	<u>-</u>
KOYO	<u>-</u>
FKL	<u>UES</u>
FKL	UYS
FKL	<u>USS</u>
FKL	LKS
FKL	<u>UEV</u>
FKL	LEV
FKL	<u>UYV</u>
FKL	LYV
FKL	<u>USV</u>
FKL	<u>LKV</u>
FKL	<u>UEU</u>
FKL	LEU
FKL	<u>UYU</u>
FKL	LYU
FKL	<u>USU</u>

INTERCHANGE	
FKL	LKU
FKL	UYF
FKL	USF
FKL	LKF
FKL	<u>UEN</u>
FKL	LEN
FKL	<u>UYN</u>
FKL	LYN
FKL	<u>USN</u>
FKL	LKN
FKL	<u>UEG</u>
FKL	LEG
FKL	<u>UYG</u>
FKL	LYG
FKL	<u>USG</u>
FKL	LKG
FKL	<u>UET</u>
FKL	<u>LET</u>
FKL	<u>UYT</u>
FKL	<u>LYT</u>
FKL	<u>UST</u>
FKL	<u>LKT</u>
FKL	<u>UEC</u>
FKL	LEC





Bearings

INTERCHANGE		INTERCHANGE	
FKL	LYC	KOYO	NAPA
FKL	USC	SKF	SYFJ.KF
FKL	LKC	NSK	<u>UKPA</u>
FKL	UED	NTN	UKUP
FKL	LED	KOYO	<u>UKPA</u>
FKL	UYD	SKF	SYF.RM
FKL	LYD	INA	PSHEY
FKL	USD	SKF	SYF TF
FKL	<u>UEP</u>	INA	RSHEY
FKL	LEP	SKF	SYF.FM
FKL	UYP	INA	PSHE
FKL	LYP	SKF	SYF.WF
FKL	USP	INA	RSHE
FKL	LKP	SKF	SYF.KF
FKL	UER	KOYO	<u></u>
FKL	LER	SKF	FYJ.FM
FKL	LYR	FAG	FG162
FKL	USR	INA	PCJ
FKL	LKR	NTN	AELF
SKF	SYJ.RM	KOYO	SAF
INA	PASEY	FAG	FG762.B
NSK	UBP	SKF	FYJ.KF
NTN	ASP	NSK	UKF
KOYO	SBP	NTN	UKF
SKF	SYJ.FM	KOYO	UKF
FAG	SG162	SKF	FYTJ.RM
INA	PASE	INA	PCJTY
NSK	ENP	NSK	UBFL
KOYO	SAP	NTN	ASFL
FAG	SG762.B	KOYO	SBFL
SKF	SYJ.KF	SKF	FYTJ.TF
NSK	UKP	INA	RCJTY
NTN	UKP	NSK	UCLF
KOYO	UKP	NTN	UCFL
SKF	SYFJ.RM	KOYO	UCFL
NSK	UBPA	SKF	FYTJ.FM
NTN	ASUP	INA	PCJT
KOYO	SBPA	NTN	AELFL
SKF	SYFJ.TF	KOYO	SAFL
NSK	UCPA	SKF	FYTJ.WF
NTN	UCUP	INA	RCJT
KOYO	UCPA	NSK	EWFL
SKF	SYFJ.FM	NTN	UELFL
NTN	AELUP	KOYO	NAFL
KOYO	SAPA	SKF	FYTJ.KF
SKF	SYFJ.WF	NSK	UKFL
NSK	EWPA	NTN	UKFL
NTN	UELUP	KOYO	UKFL
	<u></u>		<u> </u>





Bearings

INTERCHANGE		INTERCHANGE	
SKF	FYC.RM	INA	RRY
NSK	<u>UBFC</u>	SKF	PF.WF
NTN	<u>ASFC</u>	FAG	FB362.B
KOYO	SBFC	INA	RR
SKF	FYC.TF	FAG	FB762.B
NSK	UCFC	SKF	PFD.RM
NTN	<u>UCFC</u>	INA	PATRY
KOYO	<u>UCFC</u>	SKF	PFD.TF
SKF	FYC.FM	INA	RRTRY
NTN	<u>AELFC</u>	SKF	PFD.FM
SKF	FYC.WF	INA	RATR
INA	RFE	SKF	PFD.WF
NSK	<u>EWFC</u>	INA	<u>RRTR</u>
NTN	<u>UELFC</u>	SKF	PFT.RM
KOYO	<u>NAFC</u>	INA	RATY
SKF	FYC.KF	NSK	<u>UBPFL</u>
NSK	<u>UKFC</u>	NTN	ASPFL
NTN	<u>UKFC</u>	KOYO	SBPFL
KOYO	<u>UKFC</u>	SKF	PFT TF
SKF	TU.RM	INA	RRTY
NSK	<u>UBT</u>	NSK	ENPFL
NTN	AST	SKF	PFT.FM
KOYO	<u>SBT</u>	INA	RAT
SKF	TU.TF	NTN	<u>AELPFL</u>
NSK	<u>UCT</u>	KOYO	SAPFL
NTN	<u>UCT</u>	SKF	PFT.WF
KOYO	<u>UCT</u>	INA	<u>RRT</u>
SKF	TU.FM_	SKF	P.RM_
INA	PTUE	INA	PBY
NSK	ENT	NSK	<u>UBPP</u>
NTN	<u>AELT</u>	NTN	<u>ASPP</u>
KOYO	SAT	KOYO	SBPP
SKF	TU.WF	SKF	P TF
INA	RTUE	SKF	P.WF
NSK	<u>EWT</u>	FAG	<u>SB762.B</u>
NTN	<u>UELT</u>		
KOYO	NAT		
SKF	TU.KF		
NSK	<u>UKT</u>		
NTN	<u>UKT</u>		
KOYO	<u>UKT</u>		
SKF	PF.RM		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	<u>ASPF</u>		
KOYO	SBPF		
SKF	PF TF		
FAG	FB562		

