

P.WF SKF

Bearing interchange tables

TYPE: Bearing cross reference, interchange tables, Bearings and bearing units FKL



Technical specification

MANUFACTURER	SKF	INTERCHANGE	
INTERCUANCE		FKL	<u>LKU</u>
INTERCHANGE	LVD	FKL	<u>UYF</u>
FKL	LYR	FKL	USF
FAG	<u>-</u>	FKL	<u>LKF</u>
NTN	<u>-</u>	FKL	<u>UEN</u>
INA	<u> </u>	FKL	LEN
NSK		FKL	UYN
KOYO		FKL	LYN
FKL	UES	FKL	<u>USN</u>
FKL	UYS	FKL	LKN
FKL	USS	FKL	<u>UEG</u>
FKL	LKS	FKL	LEG
FKL	UEV	FKL	UYG
FKL	LEV	FKL	LYG
FKL	UYV	FKL	<u>USG</u>
FKL	LYV	FKL	LKG
FKL	USV	FKL	<u>UET</u>
FKL	<u>LKV</u>	FKL	LET
FKL	<u>UEU</u>	FKL	UYT
FKL	LEU	FKL	LYT
FKL	<u>UYU</u>	FKL	UST
FKL	LYU	FKL	LKT
FKL	<u>USU</u>	FKL	UEC
		FKL	LEC





Bearings

INTERCHANGE		INTERCHANGE	
FKL	LYC	NTN	<u>UELUP</u>
FKL	USC	коуо	NAPA
FKL	LKC	SKF	SYFJ.KF
FKL	UED	NSK	UKPA
FKL	LED	NTN	<u>UKUP</u>
FKL	UYD	коуо	UKPA
FKL	LYD	SKF	SYF.RM_
FKL	USD	INA	PSHEY
FKL	LKD	SKF	SYF TF
FKL	UEP	INA	RSHEY
FKL	LEP	SKF	SYF.FM
FKL	UYP	INA	PSHE
FKL	LYP	SKF	SYF.WF
FKL	USP	INA	RSHE
FKL	LKP	SKF	SYF.KF
FKL	UER	KOYO	<u></u>
FKL	LER	SKF	FYJ.FM_
FKL	USR	FAG	FG162
FKL	LKR	INA	PCJ
SKF	SYJ.RM	NTN	AELF
INA	PASEY	KOYO	SAF
NSK	UBP	FAG	FG762.B
NTN	ASP	SKF	FYJ.KF
KOYO	SBP	NSK	UKF
SKF	SYJ.FM	NTN	UKF
FAG	SG162	коуо	UKF
INA	PASE	SKF	FYTJ.RM_
NSK	ENP	INA	PCJTY
KOYO	SAP	NSK	UBFL
SKF	<u>-</u>	NTN	ASFL
FAG	SG762.B	KOYO	SBFL
SKF	SYJ.KF	SKF	FYTJ.TF
NSK	UKP	INA	RCJTY
NTN	<u>UKP</u>	NSK	<u>UCLF</u>
KOYO	<u>UKP</u>	NTN	<u>UCFL</u>
SKF	SYFJ.RM	KOYO	UCFL
NSK	<u>UBPA</u>	SKF	<u>FYTJ.FM</u>
NTN	<u>ASUP</u>	INA	<u>PCJT</u>
KOYO	<u>SBPA</u>	NTN	<u>AELFL</u>
SKF	SYFJ.TF	KOYO	SAFL
NSK	<u>UCPA</u>	SKF	<u>FYTJ.WF</u>
NTN	<u>UCUP</u>	INA	<u>RCJT</u>
KOYO	<u>UCPA</u>	NSK	<u>EWFL</u>
SKF	SYFJ.FM	NTN	<u>UELFL</u>
NTN	<u>AELUP</u>	KOYO	<u>NAFL</u>
коуо	SAPA	SKF	<u>FYTJ.KF</u>
SKF	SYFJ.WF	NSK	<u>UKFL</u>
NSK	EWPA	NTN	<u>UKFL</u>





Bearings

INTERCHANGE		INTERCHANGE	
KOYO	<u>UKFL</u>	FAG	FB562
SKF	FYC.RM	INA	RRY
NSK	<u>UBFC</u>	SKF	PF.WF
NTN	<u>ASFC</u>	FAG	FB362.B
KOYO	<u>SBFC</u>	INA	RR
SKF	FYC.TF	FAG	FB762.B
NSK	<u>UCFC</u>	SKF	PFD.RM
NTN	<u>UCFC</u>	INA	<u>PATRY</u>
KOYO	<u>UCFC</u>	SKF	PFD.TF
SKF	FYC.FM	INA	RRTRY
NTN	<u>AELFC</u>	SKF	PFD.FM
SKF	FYC.WF	INA	<u>RATR</u>
INA	<u>RFE</u>	SKF	PFD.WF
NSK	EWFC	INA	<u>RRTR</u>
NTN	<u>UELFC</u>	SKF	PFT.RM
KOYO	NAFC	INA	RATY
SKF	FYC.KF	NSK	<u>UBPFL</u>
NSK	UKFC	NTN	<u>ASPFL</u>
NTN	<u>UKFC</u>	коуо	<u>SBPFL</u>
KOYO	<u>UKFC</u>	SKF	PFT TF
SKF	TU.RM	INA	RRTY
NSK	<u>UBT</u>	NSK	ENPFL
NTN	<u>AST</u>	SKF	PFT.FM
KOYO	SBT	INA	RAT
SKF	<u>TU.TF</u>	NTN	<u>AELPFL</u>
NSK	<u>UCT</u>	KOYO	<u>SAPFL</u>
NTN	<u>UCT</u>	SKF	PFT.WF
KOYO	<u>UCT</u>	INA	RRT
SKF	TU.FM_	SKF	P.RM
INA	PTUE	INA	<u>PBY</u>
NSK	<u>ENT</u>	NSK	<u>UBPP</u>
NTN	AELT	NTN	ASPP
KOYO	SAT	KOYO	<u>SBPP</u>
SKF	TU.WF	SKF	<u>P TF</u>
INA	RTUE	FAG	<u>SB762.B</u>
NSK	EWT		
NTN	<u>UELT</u>		
КОУО	NAT		
SKF	<u>TU.KF</u>		
NSK	<u>UKT</u>		
NTN	<u>UKT</u>		
KOYO	<u>UKT</u>		
SKF	PF.RM		
INA	RAY		
NSK	<u>UBPF</u>		
NTN	<u>ASPF</u>		
KOYO	SBPF		
SKF	PF TF		

